

[illegible]

```
MM      MM      CCCCCCCC  HH      HH  EEEEEEEEEEE  CCCCCCCC  KK      KK  77777777  888888  000000
MM      MM      CCCCCCCC  HH      HH  EEEEEEEEEEE  CCCCCCCC  KK      KK  77777777  888888  000000
MMMM    MMMM    CC      HH      HH  EEEEEEEEEEE  CC      CC      KK      KK      77      88      88      00      00
MMMM    MMMM    CC      HH      HH  EEEEEEEEEEE  CC      CC      KK      KK      77      88      88      00      00
MM      MM      CC      HH      HH  EEEEEEEEEEE  CC      CC      KK      KK      77      88      88      00      00
MM      MM      CC      HH      HH  EEEEEEEEEEE  CC      CC      KK      KK      77      88      88      00      00
MM      MM      CC      HH      HH  EEEEEEEEEEE  CC      CC      KK      KK      77      88      88      00      00
MM      MM      CC      HH      HH  EEEEEEEEEEE  CC      CC      KK      KK      77      88      88      00      00
MM      MM      CC      HH      HH  EEEEEEEEEEE  CC      CC      KK      KK      77      88      88      00      00
MM      MM      CC      HH      HH  EEEEEEEEEEE  CC      CC      KK      KK      77      88      88      00      00
MM      MM      CC      HH      HH  EEEEEEEEEEE  CC      CC      KK      KK      77      88      88      00      00
MM      MM      CCCCCCCC  HH      HH  EEEEEEEEEEE  CCCCCCCC  KK      KK      77      888888  000000
MM      MM      CCCCCCCC  HH      HH  EEEEEEEEEEE  CCCCCCCC  KK      KK      77      888888  000000
                                     77      88      88      00      00
                                     77      88      88      00      00
                                     77      88      88      00      00
                                     77      88      88      00      00
                                     77      88      88      00      00
                                     77      88      88      00      00
                                     77      88      88      00      00
                                     77      88      88      00      00
                                     77      88      88      00      00
                                     77      88      88      00      00
                                     77      888888  000000
                                     77      888888  000000
                                     ....
                                     ....
                                     ....
                                     ....
```

```
LL      IIIIII  SSSSSSSS
LL      IIIIII  SSSSSSSS
LL      II      SS
LL      II      SS
LL      II      SS
LL      II      SS
LL      II      SSSSSS
LL      II      SSSSSS
LL      II      SS
LL      II      SS
LL      II      SS
LL      II      SS
LLLLLLLLLL  IIIIII  SSSSSSSS
LLLLLLLLLL  IIIIII  SSSSSSSS
```

(1)	59	HISTORY	: DETAILED
(2)	107	MEMORY_ROUTINES Macro	
(3)	179	SYMBOL_DEFINITIONS	
(4)	224	MEMORY CONTROLLOR AND ERROR DEFINITIONS	
(5)	282	MEMORY ACTION ROUTINE ARRAYS	
(6)	341	LOCAL DATA STORAGE	
(7)	389	MACHINE CHECK ENTRY POINT	
(8)	449	TRANSLATION BUFFER PARITY ERRORS	
(9)	479	ERRORS DETECTED IN INSTRUCTION DECODE ROMS	
(9)	480	CONTROL STORE PARITY ERRORS	
(10)	539	CACHE PARITY ERROR	
(11)	566	CP TIMEOUT / SBI ERROR CONFIRMATION	
(12)	631	READ DATA SUBSTITUTE ERROR	
(13)	730	INTERFACE FROM MACHINE CHECK HANDLER TO ERROR LOGGER	
(15)	814	SBI ERROR INTERRUPTS	
(17)	941	MEMORY TIMER SCAN	
(18)	982	Memory Error Interrupts	
(19)	1014	LOGMEM Master Routine	
(20)	1096	LOCATE_MEM Dispatching Routine	
(21)	1149	ENAB Action Routines	
(22)	1200	LOGMEM Action Routines	
(23)	1253	LOG_MS780C	
(24)	1322	LOG_MS780E	
(25)	1458	LOG_MA780	
(26)	1618	TABLE OF RESUMABLE INSTRUCTIONS.	



```
0000 1      .NLIST CND
0000 3      .TITLE MCHECK780 - MACHINE CHECK EXCEPTION HANDLER FOR 11/780
0000 7
0000 8      .IDENT 'V04-000'
0000 9
0000 10     *****
0000 11     *
0000 12     *  COPYRIGHT (c) 1978, 1980, 1982, 1984 BY
0000 13     *  DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.
0000 14     *  ALL RIGHTS RESERVED.
0000 15     *
0000 16     *  THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED
0000 17     *  ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE
0000 18     *  INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER
0000 19     *  COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY
0000 20     *  OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY
0000 21     *  TRANSFERRED.
0000 22     *
0000 23     *  THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE
0000 24     *  AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT
0000 25     *  CORPORATION.
0000 26     *
0000 27     *  DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS
0000 28     *  SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
0000 29     *
0000 30     *
0000 31     *****
0000 32
0000 33     ++
0000 34     : FACILITY:      EXECUTIVE, ERROR HANDLING
0000 35
0000 36     : ABSTRACT: IN A NUTSHELL, LOG IT AND TRY TO RECOVER.
0000 37
0000 38     : ENVIRONMENT: RUNS ON INTERRUPT STACK AT IPL 31 UNTIL ERROR TYPE IS KNOWN
0000 39     :                  AND (IF POSSIBLE) CORRECTED, THEN RUNS AT SYNCH LEVEL
0000 40     :                  TO DO THE ERROR LOGGING.
0000 41
0000 42
0000 43
0000 44
0000 45
0000 46
0000 47
0000 48     :--
0000 49     :      .SBTTL HISTORY                      ; DETAILED
0000 50
0000 51     :
0000 52     :  AUTHOR: RICHARD LARY , CREATION DATE: 6-NOV-77
0000 53
0000 54     :  MODIFIED BY:
0000 55
0000 56     :
0000 57     :
0000 58     :
0000 59     :
0000 60     :
0000 61     :
0000 62     :
0000 63     :
0000 64     :
0000 65     :      V03-013 WMC0002      Wayne Cardoza      25-Jul-1984
0000 66     :                  Add H memory to the tables.
0000 67     :
0000 68     :      V03-012 WMC0001      Wayne Cardoza      14-Jun-1984
0000 69     :                  Preserve cache state when handling machine check.
0000 70     :                  Properly clear group 1 cache parity errors.
0000 71     :
0000 72     :      V03-011 NPK3049      N. Kronenberg      10-Apr-1984
0000 73     :                  Tighten up check for BRRVR reference from unibus
0000 74     :                  interrupt service routine in CPTIMOUT. Test for
0000 75     :                  PC as well as VA.
0000 76     :
0000 77     :      V03-010 RLRSBICONF    Robert L. Rappaport    22-Mar-1984
```

0000	78	:	Test MMG\$GL_SBICONF array elements for valid system
0000	79	:	virtual address (high bit set) before using. Also
0000	80	:	correct error introduced by CONFREGL change.
0000	81	:	
0000	82	:	V03-009 KPL0100 Peter Lieberwirth 10-Feb-1984
0000	83	:	Change to use CONFREGL.
0000	84	:	
0000	85	:	V03-008 KDM0053 Kathleen D. Morse 11-Jul-1983
0000	86	:	Replace cpu-specific IPR references with the new
0000	87	:	cpu-specific \$PR780DEF symbols.
0000	88	:	
0000	89	:	V03-007 TCM0011 Trudy C. Matthews 24-Jan-1983
0000	90	:	Correct bug in MA780 logging routine that checked for
0000	91	:	Multiple Interlock Accepted error bit in the wrong
0000	92	:	MA780 register.
0000	93	:	
0000	94	:	V03-006 KDM0040 Kathleen D. Morse 13-Jan-1983
0000	95	:	Change PRMSW to MPSWITCH and integrate into multi-processing
0000	96	:	code replacing [MP.SRC]MPMCHECK.MAR. Fix bug that referenced
0000	97	:	devices attached to primary (via CONFREG array) from the
0000	98	:	secondary processor's machine-check code.
0000	99	:	
0000	100	:	V03-005 RNG0001 Rod N. Gamache 15-Oct-1982
0000	101	:	Fixed code that enabled the MS780-E memory CRD (corrected
0000	102	:	read data) interrupts. Fixed code that re-enabled the MS780-C
0000	103	:	CRD interrupts.
0000	104	:	
0000	105	:	



```
0000 107 .SBTTL MEMORY_ROUTINES Macro
0000 108 :++
0000 109 Macro MEMORY_ROUTINES
0000 110 Build action routine vectors for different memory types.
0000 111 :
0000 112 Inputs:
0000 113 MEMTYPES - A list of 'NDTS' type codes for this controller.
0000 114 LOGERR_RTN - Action routine that determines if an error was
0000 115 reported for this controller; if so, it logs it.
0000 116 LOGALL_RTN - Action routine to unconditionally log this
0000 117 controller's registers.
0000 118 ENAB_RTN - Action routine to enable CRD interrupts for this
0000 119 memory controller.
0000 120 :
0000 121 Outputs:
0000 122 Additions to LOGERR_ROUTINES, LOGALL_ROUTINES, and ENAB_ROUTINES arrays.
0000 123 :
0000 124 Note: Each invocation of this macro corresponds to one "general" memory type.
0000 125 Each element in MEMTYPES list corresponds to one "specific" type.
0000 126 :
0000 127 -- .MACRO MEMORY_ROUTINES MEMTYPES,LOGERR_RTN,LOGALL_RTN,ENAB_RTN
0000 128 .SAVE
0000 129 :
0000 130 Create arrays to map a set of specific type codes to one general memory type.
0000 131 Note: Psects MCHK$DATA0 and MCHK$DATA1 must be contiguous.
0000 132 :
0000 133 .IRP MEMTYP, MEMTYPES ; Repeat for each memory type...
0000 134 :
0000 135 .IF NDF,MPSWITCH ;***** ONLY PRIMARY PROCESSOR...
0000 136 .PSECT MCHK$DATA0, LONG, WRT ; Add specific-type entry to MEMTYP
0000 137 .IFF ;***** ONLY SECONDARY PROCESSOR...
0000 138 .PSECT Y$MPDATA0, LONG, WRT ; Add specific-type entry to MEMTYP
0000 139 .ENDC ;***** PRIMARY and SECONDARY PROCESSORS
0000 140 .BYTE MEMTYP ; array.
0000 141 :
0000 142 .IF NDF,MPSWITCH ;***** ONLY PRIMARY PROCESSOR...
0000 143 .PSECT MCHK$DATA1 ; Add general-type entry to MEMTYP
0000 144 .IFF ;***** ONLY SECONDARY PROCESSOR...
0000 145 .PSECT Y$MPDATA1 ; Add general-type entry to MEMTYP
0000 146 .ENDC ;***** PRIMARY and SECONDARY PROCESSORS
0000 147 .BYTE GENERAL_MEMTYP
0000 148 :
0000 149 MEMTYP CNT = MEMTYP CNT + 1
0000 150 .ENDR
0000 151 GENERAL_MEMTYP = GENERAL_MEMTYP + 1
0000 152 :
0000 153 Now create action routine vectors.
0000 154 :
0000 155 .IF NDF,MPSWITCH ;***** ONLY PRIMARY PROCESSOR...
0000 156 .PSECT MCHK$DATA2, LONG, WRT ; LOGERR_ROUTINES array:
0000 157 .IFF ;***** ONLY SECONDARY PROCESSOR...
0000 158 .PSECT Y$MPDATA2, LONG, WRT ; LOGERR_ROUTINES array:
0000 159 .ENDC ;***** PRIMARY and SECONDARY PROCESSORS
0000 160 .LONG <LOGERR_RTN-.> ; Add self-relative offset to routine.
0000 161 :
0000 162 .IF NDF,MPSWITCH ;***** ONLY PRIMARY PROCESSOR...
0000 163 .PSECT MCHK$DATA3, LONG, WRT ; LOGALL_ROUTINES array:
```

0000	164	.IFF		:***** ONLY SECONDARY PROCESSOR...
0000	165	.PSECT	YSMPDATA3, LONG, WRT	: LOGALL_ROUTINES array:
0000	166	.ENDC		:***** PRIMARY and SECONDARY PROCESSORS
0000	167	.LONG	<LOGALL_RTN-.>	: Add self-relative offset to routine.
0000	168			
0000	169	.IF	NDF, MPSWITCH	:***** ONLY PRIMARY PROCESSOR...
0000	170	.PSECT	MCHK\$DATA4, LONG, WRT	: ENAB_ROUTINES array:
0000	171	.IFF		:***** ONLY SECONDARY PROCESSOR...
0000	172	.PSECT	YSMPDATA4, LONG, WRT	: ENAB_ROUTINES array:
0000	173	.ENDC		:***** PRIMARY and SECONDARY PROCESSORS
0000	174	.LONG	<ENAB_RTN-.>	: Add self-relative offset to routine.
0000	175			
0000	176	.RESTORE		
0000	177	.ENDM	MEMORY_ROUTINES	

```
.SBTTL SYMBOL DEFINITIONS

0000 179
0000 180
0000 181
0000000A 0000 182 CH_THRESHOLD = 10. ;3 ERRORS IN 100 MS TO DISABLE CACHE
00010000 0000 183 CH_MISSGO = ^X10000 ;'FORCE MISS GROUP 0' BIT
00008000 0000 184 CH_MISSG1 = ^X8000 ;'FORCE MISS GROUP 1' BIT
00004000 0000 185 CH_REPLGO = ^X4000 ;'FORCE REPLACE GROUP 0' BIT
00002000 0000 186 CH_REPLG1 = ^X2000 ;'FORCE REPLACE GROUP 1' BIT
0000000D 0000 187 CHSV_REPLG1 = 13
00000004 0000 188 CHSS_CONTROL = 4 ;SIZE OF CACHE CONTROL FIELD
0021C000 0000 189 CH_REPAIR = ^X21C000 ;BITS TO SET IN SBIMT ON CACHE ERRORS
0021A000 0000 190 CH_REPAIR_1 = ^X21A000 ;BITS CLEAR GROUP 1 CACHE ERRORS
00000003 0000 191 CHSV_GOERRS = 3 ;START OF GROUP 0 ERRORS IN PARITY REG
00000007 0000 192 CHSS_GOERRS = 7 ;LENGTH OF GROUP 0 ERROR BITS
00000001 0000 193 CHLOG_DISAB0 = 1 ;LOG BIT SAYING WE DISABLED GROUP 0
00000002 0000 194 CHLOG_DISAB1 = 2 ;LOG BIT SAYING WE DISABLED GROUP 1
0000 195
0000 196
00000019 0000 197 SBIFSV_NEF = 25 ;NESTED ERROR FLAG IN SBI FAULT/STATUS
0000 198
0000 199 ;THE FOLLOWING 5 DEFINITIONS ARE IN THE SBI ERROR REGISTER
00000040 0000 200 SBIERSM_IBTO = ^X40 ;IB TIMEOUT LATCH
00000080 0000 201 SBIERSM_IBRDS = ^X80 ;IB RDS LATCH
00001000 0000 202 SBIERSM_CPTO = ^X1000 ;CP TIMEOUT LATCH
00002000 0000 203 SBIERSM_RDS = ^X2000 ;RDS LATCH
00004000 0000 204 SBIERSM_CRD = ^X4000 ;CRD LATCH
0000 205
0000 206
0000 207 ; MACHINE CHECK HARDWARE LOG OFFSETS
0000 208
00000000 0000 209 MCL_COUNT = 0 ;BYTE LENGTH OF AREA (28 HEX)
00000004 0000 210 MCL_SUMMARY = 4 ;SUMMARY WORD - BYTE 0=CODE, BYTE 1=
0000 211 ;TIMEOUT PENDING FLAG
00000008 0000 212 MCL_CES = 8 ;CPU ERROR STATUS
0000000C 0000 213 MCL_UPC = 12. ;MICRO-PC AT FAULT TIME
00000010 0000 214 MCL_VA = 16. ;VIRTUAL ADDR AT FAULT TIME
00000014 0000 215 MCL_D = 20. ;CPU D REGISTER AT FAULT TIME
00000018 0000 216 MCL_TBERO = 24. ;TRANSLATION BUFFER STATUS REG 0
0000001C 0000 217 MCL_TBER1 = 28. ;TBUF STATUS REG 1
00000020 0000 218 MCL_TIMOADDR = 32. ;PHYSICAL ADDRESS CAUSING SBI TIMEOUT
00000024 0000 219 MCL_PARITY = 36. ;CACHE STATUS REGISTER
00000028 0000 220 MCL_SBIERR = 40. ;SBI ERROR REGISTER
0000002C 0000 221 MCL_PC = 44. ;PC OF INSTRUCTION WHICH CAUSED CHECK
00000030 0000 222 MCL_PSL = 48. ;PSL OF MACHINE AT FAULT TIME
```



```
0000 224 .SBTTL MEMORY CONTROLLOR AND ERROR DEFINITIONS
0000 225
0000 226
0000 227 : Common error bit definitions.
0000 228
0000001C 0000 229 MRCSV_ELSRF = 28 :ERROR LOG SERVICE REQUEST
10000000 0000 230 MRCSM_ELSRF = ^X10000000 :WRITE 1 TO CLEAR FLAG
0000001D 0000 231 MRCSV_HERIMF = 29 :HIGH ERROR RATE IN MEMORY
20000000 0000 232 MRCSM_HERIMF = ^X20000000 :WRITE 1 TO CLEAR FLAG
0000001E 0000 233 MRCSV_INHBCRD = 30 :1 DISABLES CRD INTERRUPT
40000000 0000 234 MRCSM_INHBCRD = ^X40000000 :0 CRD INTERRUPT ENABLE, 1 CRD DISABLE
0000 235
0000 236 : MA780-specific error bit definitions (in Array Error Register).
0000 237
0000001F 0000 238 MRCSV_INVMAPPTY = 31 :INVALID MAP PARITY ERROR
80000000 0000 239 MRCSM_INVMAPPTY = ^X80000000 :WRITE 1 TO CLEAR THE FLAG
0000 240
0000 241 : MS780E-specific error bit definitions.
0000 242
00000014 0000 243 MRCSV_SUMMARY = 20 :ERROR SUMMARY BIT
00100000 0000 244 MRCSM_SUMMARY = ^X00100000 :OR OF ALL ERROR BITS -- READ ONLY
00000013 0000 245 MRCSV_CTL1PTY = 19 :PARITY ERROR ON READ DATA FROM
00080000 0000 246 MRCSM_CTL1PTY = ^X00080000 :CONTROLLER 1 TO SBI INTERFACE.
00000012 0000 247 MRCSV_CTLOPTY = 18 :PARITY ERROR ON READ DATA FROM
00040000 0000 248 MRCSM_CTLOPTY = ^X00040000 :CONTROLLER 0 TO SBI INTERFACE.
0000 249 :FOLLOWING BITS ARE IN REGISTERS C & D
00000007 0000 250 MRCSV_MSEQPTY = 7 :MICROSEQUENCER PARITY ERROR
00000080 0000 251 MRCSM_MSEQPTY = ^X00000080
00000008 0000 252 MRCSV_IFPTY = 8 :PARITY ERROR ON WRITE DATA FROM
00000100 0000 253 MRCSM_IFPTY = ^X00000100 :SBI INTERFACE TO CONTROLLER.
00000009 0000 254 MRCSV_CRDERR = 9 :CORRECTED READ DATA ERROR
00000200 0000 255 MRCSM_CRDERR = ^X00000200
0000 256
00000384 0000 257 REENABTIME = 60*15 :REENABLE INTERRUPT ERROR LOGGING
0000 258 :EVERY 15 MINUTES
0000003C 0000 259 SOMETIME = 60 :SCAN FOR NON-INTERRUPT ERRORS
0000 260 :EVERY 60 SECONDS
00000003 0000 261 CRDINTMAX = 3 :MAXIMUM NUMBER OF INTERRUPTS A CONT
0000 262 :IS ALLOWED WITHIN REENABTIME
00000006 0000 263 CRDWATCHMAX = 6 :MAXIMUM NUMBER OF ERRORS TO BE LOGGED
0000 264 :WITHIN REENABTIME
0000 265
0000 266 : INCLUDED SYMBOL DEFINITIONS
0000 267
0000 268 $ADPDEF :DEFINE ADAPTER CONTROL BLOCK SYMBOLS
0000 269 $EMBDEF <MC,SB,SE> :DEFINE EMB OFFSETS
0000 270 $IPLDEF :PROCESSOR INTERRUPT LEVELS
0000 271 $MCHKDEF :DEFINE RECOVERY BLOCK MASK BITS
0000 272 $NDTDEF :DEFINE NEXUS DEVICE TYPES
0000 273 $PCBDEF :PROCESS CTL BLOCK
0000 274 $PFNDEF :PFN DATA BASE
0000 275 $PRDEF :DEFINE PROCESSOR REGISTER NUMBERS
0000 276 $PR780DEF :DEFINE 780-SPECIFIC PROCESSOR REGISTERS
0000 277 $PSLDEF :DEFINE PSL
0000 278 $PTEDEF :PTE SYMBOLS
0000 279 $SSDEF :DEFINE SYSTEM STATUS VALUES
0000 280 $VADEF :DEF IN PFN PITS
```

```
0000 282 .SBTTL MEMORY ACTION ROUTINE ARRAYS
0000 283
00000000 285 .PSECT MCHK$DATA0, LONG, WRT
0000 289 MEMTYP: ; Define base of array of memory type
0000 290 ; codes.
00000000 292 .PSECT MCHK$DATA2, LONG, WRT
0000 296 LOGERR_ROUTINES: ; Define base of array of routines to
0000 297 ; log memories with errors.
00000000 299 .PSECT MCHK$DATA3, LONG, WRT
0000 303 LOGALL_ROUTINES: ; Define base of array of routines to
0000 304 ; unconditionally log memories.
00000000 306 .PSECT MCHK$DATA4, LONG, WRT
0000 310 ENAB_ROUTINES: ; Define base of array of routines to
0000 311 ; enable CRD interrupts in memories.
0000 312 ;
0000 313 ; The following macro invocations add elements to the above arrays for each
0000 314 ; memory type.
0000 315 ;
0000 316
00000000 0000 317 MEMTYP CNT = 0
00000000 0000 318 GENERAL_MEMTYP = 0
0000 319
0000 320 MEMORY_ROUTINES - ; MS780C memory controller.
0000 321 MEMTYPES=<NDTS_MEM4NI,NDTS_MEM4I,NDTS_MEM16NI,NDTS_MEM16I>, -
0000 322 LOGERR_RTN = LOG_MS780C, -
0000 323 LOGALL_RTN = LOGC, -
0000 324 ENAB_RTN = ENAB_MS780C
0000 325
0000 326 MEMORY_ROUTINES - ; MA780 memory controller.
0000 327 MEMTYPES=<NDTS_MPM0,NDTS_MPM1,NDTS_MPM2,NDTS_MPM3>, -
0000 328 LOGERR_RTN = LOG_MA780, -
0000 329 LOGALL_RTN = LOGMA, -
0000 330 ENAB_RTN = ENAB_MA780
0000 331
0000 332 MEMORY_ROUTINES - ; MS780E memory controller.
0000 333 MEMTYPES=<NDTS_MEM64NIL,NDTS_MEM64EIL,NDTS_MEM64NIU, -
0000 334 NDT$_MEM64EIU,NDTS_MEM64I, -
0000 335 NDT$_MEM256NIL,NDTS_MEM256EIL,NDTS_MEM256NIU, -
0000 336 NDT$_MEM256EIU,NDTS_MEM256I>, -
0000 337 LOGERR_RTN = LOG_MS780E, -
0000 338 LOGALL_RTN = LOGE, -
0000 339 ENAB_RTN = ENAB_MS780E
```

```
0000 341 .SBTTL LOCAL DATA STORAGE
0000 342
0000 343
0000 344 : Macro that will define a global name of the form MPSS if
0000 345 : MPSSWITCH is defined, else EXES. It will also define a local name
0000 346 : to be used within this module.
0000 347 :
0000 348 .MACRO GBLDEF NAME
0000 349 .IF DF,MPSSWITCH ; For secondary processor only code...
0000 350 MPSS'NAME'::
0000 351 .IFF ; For MCHECK780...
0000 352 EXES'NAME'::
0000 353 .ENDC
0000 354 'NAME': ; For local use...
0000 355 .ENDM GBLDEF
0000 356
0000 357
0000 358 .PSECT MCHK$DATA,QUAD,WRT
0000 359 : The following symbol is defined for a transfer vector in SYSLOAVEC
0000 360 : This location is NEVER JUMPED TO. It is defined so these counters
0000 361 : Can be located using a global symbol in the system map.
0000 362
0000 363
0000 364
0000 365
0000 366 GBLDEF MCHK_ERRCNT ;GLOBAL SYMBOL FOR SYSLOAVEC POINTER
0000 367 GBLDEF GL_CSBITA ;USED TO HOLD COMPLEMENT OF SBITA
00000000 0000 368 .LONG 0
00000000 0004 369 GBLDEF GL_CH1OLD ;TIME OF LAST CACHE ERROR
00000000 0004 370 .LONG 0
00000000 0008 371 GBLDEF GL_CH2OLD ;TIME OF NEXT-TO-LAST CACHE ERROR
00000000 0008 372 .LONG 0
00000000 000C 373 GBLDEF GL_CPTIMOUT ;TIME OF LAST CP TIMEOUT/SBI ERROR
00000000 000C 374 .LONG 0
00000020 0010 375 GBLDEF AB_MEMERR ;ERROR COUNTERS FOR 16 ADAPTERS
00000020 0010 376 .B[KB 16
0000 0020 377 GBLDEF GW_REENAB ;REENABLE TIMER
0000 0020 378 .WORD 0
0000 0022 379 GBLDEF GW_WATCH ;SCAN MEMORY CONTROLLER TIMER
0000 0022 380 .WORD 0
00000000 0024 381 GBLDEF GL_CRDCNT ;COUNT OF CORRECTED MEMORY ERRORS
00000000 0024 382 .LONG 0
00200000 0028 383 GBLDEF GL_CHSTATE ;CURRENT STATE OF CACHE
00200000 0028 384 .LONG *X200000
00000000 002C 385 GBLDEF GL_BADTIMOUT ;TIME SINCE LAST BAD MCHK CODE
00000000 002C 386 .LONG 0
0030 387
```



```
0030 389 .SBTTL MACHINE CHECK ENTRY POINT
00000000 391 .PSECT MCHK$CODE, LONG, WRT
0000 395
0000 396 : MACHINE CHECK ENTRY POINT - SCB VECTOR POINTS HERE.
0000 397 : IPL ^X1F = 31
0000 398
0000 399 .ALIGN LONG ;A VECTOR MUST HAVE LONGWORD ALIGNMENT
0000 400 GBLDEF MCHK ;EITHER EXESMCHK:: OR MPSSMCHK::
0000 401
0000 402 PUSHL #MCHK$M_LOG ;MASK WORD FOR PRCTEST
30 AE DF 0002 403 PUSHAL MCL_PC+4(SP) ;PC,PSL POINTER FOR PRCTEST
103F 8F BB 0005 404 PUSHR #^M<R0,R1,R2,R3,R4,R5,AP>
5C 5E 24 C1 0009 405 ADDL3 #<9*4>,SP,AP ;POINT AP TO LOG FRAME ON STACK
0000 406 ;ALL INTERRUPTS ARE LOCKED OUT!
0000 407
50 50 50 33 DB 000D 408 MFPR #PR780$ SBIMT,R0 ;GET CURRENT CACHE STATE
50 50 F3 8F 78 0010 409 ASHL #CHSV REPLG1,R0,R0 ;POSITION THE CACHE CONTROL BITS
OD 50 FO 0015 410 INSV R0,#CHSV REPLG1,- ;SAVE THE CURRENT CACHE CONTROL BITS
0028'CF 04 0018 411 #CH$S CONTROL,W^GL_CHSTATE
33 0021C000 8F DA 001C 412 MTPR #CH_REPAIR,#PR780$ SBIMT ;FORCE MISSES AND GROUP 0 REPLACE,
0023 413 ; BUT ALLOW SBI TO INVALIDATE CACHE
7E 04 AC FO 8F 8B 0023 414 BICB3 #^XFO,MCL_SUMMARY(AP),-(SP) ;GET LOW 4 BITS OF TYPE CODE
0029 415 CASE (SP)+,<- ;BREAKOUT TYPE CODE
0029 416 CPTIMEOUT,- ;CPU TIMEOUT/SBI ERROR CONFIRMATION
0029 417 CSPARITY,- ;CONTROL STORE PARITY ERROR
0029 418 TBUFPARITY,- ;TRANSLATION BUFFER PARITY ERROR
0029 419 CACHEPARITY,- ;CACHE PARITY ERROR
0029 420 BADTYPE,- ;THIS CODE DOESN'T EXIST
0029 421 READSUBST,- ;READ DATA SUBSTITUTE (MEM READ ERROR)
0029 422 IBROMCHECK,- ;'CAN'T GET HERE' ERROR FROM INST ROMS
0029 423 BADTYPE,-
0029 424 BADTYPE,-
0029 425 BADTYPE,-
0029 426 TBUFPARITY,- ;IB-DETECTED TBUF ERROR
0029 427 BADTYPE,-
0029 428 READSUBST,- ;IB-DETECTED MEMORY ERROR
0029 429 CPTIMEOUT,- ;IB-DETECTED TIMEOUT OR SBI ERROR CONF
0029 430 BADTYPE,-
0029 431 CACHEPARITY>, TYPE=B ;IB-DETECTED CACHE PROBLEM
004D 432
004D 433 BADTYPE:
33 0028'CF DA 004D 434 MTPR W^GL_CHSTATE,#PR780$ SBIMT ;RE-ENABLE THE CACHE
FC AC 02 C8 0052 435 BISL #MCHK$M MCK,-4(AP) ;MASK FOR PRCTEST
002C'CF DD 0056 436 PUSHL W^GL_BADTIMOUT ;TIME OF LAST BAD TYPE FAULT
002C'CF 1B DB 005A 437 MFPR #PR780$ TODR,W^GL_BADTIMOUT ;TIME OF CURRENT FAULT
002C'CF 8E D1 005F 438 CMPL (SP)+,W^GL_BADTIMOUT ;COMING TO FAST?
20 12 0064 439 BNEQ DAMPUATE ;YES, ABORT
103F 8F BA 0066 440 100$: POPR #^M<R0,R1,R2,R3,R4,R5,AP>
00000000'GF 16 006A 441 JSB G^EXESMCHK BUGCHK ;RECOVERY BLOCK ENABLED?
0070 444 BUG_CHECK BADMCKCDB,FATAL ;BAD MACHINE CHECK CODE
```

```
0074 449 .SBTTL TRANSLATION BUFFER PARITY ERRORS
0074 450
0074 451 TBUFParity:
0074 452 MTPR W^GL CHSTATE,#PR780$ _SBINT ;RE-ENABLE CACHE
0079 453 MTPR #0,#PR$ _TBIA ;CLEAR ENTIRE TBUF
007C 454 BISL #MCHK$M_MCK,-4(AP) ;SET MACHINE CHECK CODE FOR PRtCTEST
0080 455
0080 456
0080 457 TRYRESUME:
0080 458 BITW #^X1F0,MCL_SUMMARY(AP) ;IS ERROR ABORT OR TIMEOUT PENDING
0086 459 DAMPUTATE:
0086 460 BNEQ AMPUTATE ;BRANCH IF YES, NO HOPE OF RESUMING
0088 461 BITB #8,MCL_SUMMARY(AP) ;SEE IF ERROR WAS IB ERROR
008C 462 BNEQ 10$ ;IF SO, WE CAN "DEFINITELY" RESUME
008E 463 MOVZBL @MCL_PC(AP),-(SP) ;GET OPCODE FOR RESTARTABILITY CHECK
0092 464 BBC (SP)+,W^RESUMABLE,AMPUTATE ;BRANCH IF INST NOT RESUMABLE,ABORT
0098 465 10$: ;THERE IS A LOW PROBABILITY CASE HERE THAT MAY ALLOW THIS CODE TO
0098 466 ;CONTINUE WHEN WE CAN'T - IF A LOCATION IS READ FROM THE IO PAGE AND
0098 467 ;HAS A SIDE AFFECT WHICH MODIFIES THAT LOCATION, THE INSTRUCTION IS
0098 468 ;NOT RETRYABLE, A SOFTWARE SOLUTION IS TO IMPLEMENT A FLAG SET BY ANY
0098 469 ;POTENTIAL REFERENCE TO THE IO PAGE THAT MAY CAUSE A SIDE AFFECT.
0098 470 ;BBS #IOSAFLAG,FLAG,AMPUTATE ;BRANCH IF INST MAY OF HAD SIDE AFFECT
0098 471 RESUME:
0098 472 MOVW #EMB$K_MC,R3 ;SET TYPE OF LOG ENTRY
009B 473 BSBW LOGGR ;WE'RE GOING TO MAKE IT - LOG ERROR
009E 474 POPR #^M<R0,R1,R2,R3,R4,R5,AP> ;RESTORE REGISTERS
00A2 475 ADDL #8,SP ;REMOVE PRtCTEST STUFF FROM STACK
00A5 476 ADDL (SP)+,SP ;POP HARDWARE LOG FROM STACK
00A8 477 REI ;AND TRY AGAIN
```

33 0028'CF DA 0074 452  
39 00 DA 0079 453  
FC AC 02 CB 007C 454  
0080 455  
0080 456  
04 AC 01F0 8F B3 0080 458  
0086 459  
04 AC 2F 12 0086 460  
08 93 0088 461  
0A 12 008C 462  
7E 2C BC 9A 008E 463  
1F 070D'CF 8E E1 0092 464  
0098 465  
0098 466  
0098 467  
0098 468  
0098 469  
0098 470  
0098 471  
53 02 B0 0098 472  
022E 30 009B 473  
103F 8F BA 009E 474  
5E 08 C0 00A2 475  
5E 8E C0 00A5 476  
02 00A8 477

			00A9	479	.SBTTL	ERRORS DETECTED IN INSTRUCTION DECODE ROMS
			00A9	480	.SBTTL	CONTROL STORE PARITY ERRORS
			00A9	481		
			00A9	482	IBROMCHECK:	
			00A9	483	CSPARITY:	
33	0028'CF	DA	00A9	484	MTPR	W^GL_CHSTATE,#PR780\$ SBINT ;CACHE PROBABLY OK - ENABLE IT
06 AC	2C BC	90	00AE	485	MOVB	@MCL_PC(AP),MCL_SUMMARY+2(AP) ;SAVE OPCODE IN LOG
FC AC	02	C8	00B3	486	BISL	#MCHK\$M_MCK,-4(AP) ;SET MASK CODE FOR PRTCTEST
			00B7	487	AMPUTATE:	
53	02	B0	00B7	488	MOVW	#EMBSK_MC,R3 ;SET TYPE OF LOG ENTRY
	020F	30	00BA	489	BSBW	LOGGER ;LOG THE ERROR
0E 30 AC	19	E0	00BD	490	BBS	#PSL\$V_CURMOD+1,MCL_PSL(AP),REFLECTCHK ;BRANCH IF
			00C2	491		;FAILURE IN USER OR SUPERVISOR MODE
			00C2	492		
103F 8F		BA	00C2	493	POPR	#^M<R0,R1,R2,R3,R4,R5,AP> ;RESTORE REGS
00000000'GF		16	00C6	495	JSB	G^EXE\$MCHK BUGCHK ;RECOVERY BLOCK IN EFFECT?
			00CC	496	BUG_CHECK	MACHINECHK,FATAL ;MACHINE CHECK IN KERNEL OR EXEC MODE
			00D0	500		
			00D0	510	REFLECTCHK:	
50	00	DB	00D0	511	MTPR	#PR\$ KSP,R0 ;GET THE KERNEL MODE STACK POINTER
70	2C AC	7D	00D3	512	MOVQ	MCL_PC(AP),-(R0) ;INTERRUPT PC,PSL TO KERNEL STACK
			00D7	513		;IT IS NOT NECCESARY TO PROBE KERNEL
			00D7	514		;STACK FOR VALIDITY, THE FAILURE WILL
			00D7	515		;BE A KERNEL STACK NOT VALID BUGCHECK
			00D7	516		;FROM WITHIN MACHINE CHECK
00	50	DA	00D7	517	MTPR	R0,#PR\$ KSP ;REPLACE THE NEW KERNEL STACK POINTER
103F 8F		BA	00DA	518	POPR	#^M<R0,R1,R2,R3,R4,R5,AP> ;RESTORE REGISTERS
5E	08	C0	00DE	519	ADDL	#8,SP ;CLEAR PRTCTST STUFF
5E	8E	C0	00E1	520	ADDL	(SP)+,SP ;POP HARDWARE LOG FROM STACK
6E	00000000'GF	9E	00E4	521	MOVAB	G^EXE\$MCHK,(SP) ;SET UP A PC AND PSL FOR EXCEPTION
04 AE	04 AE	02	00EB	522	EXTZV	#PSL\$V_CURMOD,#PSL\$S_CURMOD,4(SP),4(SP)
			00F2	523		;GET MODE WE WERE EXECUTING IN
04 AE	04 AE	16	00F2	524	ROTL	#PSL\$V_PRVMOD,4(SP),4(SP) ;CREATE A PSL OF CURRENT TO BE
			00F8	525		;KERNEL WITH CORRECT PREVIOUS MODE
			00F8	526		;AS FROM A FAULT, 0'S IN REST OF PSL
		02	00F8	528	REI	;GET TO EXCEPTION HANDLER



				00F9	539		
				00F9	540		
				00F9	541	.SBTTL CACHE PARITY ERROR	
				00F9	542	CACHEPARITY:	
				00F9	543	:ENTER WITH CACHE DISABLED REPLACING	
				00F9	544	: GROUP 0	
				00FD	545	:SET MACHINE CHECK TYPE FOR PRCTEST	
				0100	546	:FORCE DATA INTO GROUP 0 OF BAD CACHE	
				0107	547	:NOW FORCE GROUP 1 REPLACEMENT AND	
				010A	548	:FORCE GROUP 1 OF BAD LINE TO GOOD DATA	
				010D	549	:GET TIME-OF-YEAR IN 10MS TICKS	
				0113	550	:GET TIME SPAN OF LAST 2 ERRORS-NOW	
				0116	551	:ARE THE ERRORS WIDELY SPACED	
				0118	552	:BRANCH IF YES TO FORGIVE THE CACHE	
				0122	553	:MCL PARITY(AP),#B1111111	
				0122	554	:IS GROUP 0 ALL GOOD?	
				0124	555	:BRANCH IF GROUP 0 WAS BAD	
				012A	556	:DISABLE GROUP 1	
				012F	557	:CANNOT FORCE REPLACE IN BOTH	
				0133	558	:LOG THAT WE DID IT	
				0135	559	:DISABLE GROUP 0	
				013C	560	:DON'T FORCE REPLACE IN BOTH!	
				0142	561	:LOG THAT WE DID IT	
				0146	562	:MAINTAIN THE TIMING HISTORY	
				014D	563	:UNTO THE THIRD GENERATION	
				0152	564	:RE-ENABLE THE CACHE - FINALLY!	
				0157	565	:SEE IF WE CAN CONTINUE FROM THE ERROR	

  

FC AC	02	C8	00F9	539	BISL	#MCHKSH MCK,-4(AP)	
10 BC	95	00FD	540	TSTB	@MCL VA(AP)		
33 0021A000	8F	DA	0100	MTPR	#CH REPAIR 1,#PR780\$-SBIMT		
10 BC	95	0107	546	TSTB	@MCL VA(AP)		
7E 7E	1B	DB	010A	MFPR	#PR780\$ TODR,-(SP)		
7E 6E	0008'CF	C3	010D	SUBL3	W^GL CH2OLD,(SP),-(SP)		
0A	8E	D1	0113	CMPL	(SP)+,#CH_THRESHOLD		
2E		1A	0116	BGTRU	20\$		
0000007F 8F	24 AC	07	03	ED	0118	#CHSV_GOERRS,#CHSS_GOERRS	
					0122	MCL PARITY(AP),#B1111111	
					0122	:IS GROUP 0 ALL GOOD?	
					0122	:BRANCH IF GROUP 0 WAS BAD	
0029'CF	C0	8F	88	0124	554	:DISABLE GROUP 1	
0029'CF	20		8A	012A	555	:CANNOT FORCE REPLACE IN BOTH	
07 AC	02		90	012F	556	:LOG THAT WE DID IT	
			11	0133	557		
0029'CF	0120	8F	A8	0135	558	:DISABLE GROUP 0	
0029'CF	40	8F	8A	013C	559	:DON'T FORCE REPLACE IN BOTH!	
07 AC	01		90	0142	560	:LOG THAT WE DID IT	
0008'CF	0004'CF		D0	0146	561	:MAINTAIN THE TIMING HISTORY	
0004'CF	8E		D0	014D	562	:UNTO THE THIRD GENERATION	
33	0028'CF		DA	0152	563	:RE-ENABLE THE CACHE - FINALLY!	
	FF26		31	0157	564	:SEE IF WE CAN CONTINUE FROM THE ERROR	

```
015A 566 .SBTTL CP TIMEOUT / SBI ERROR CONFIRMATION
015A 567
015A 568 CPTIMEOUT:
015A 569 MTPR W^GL CHSTATE,#PR780$ SBIMT ;ENABLE THE CACHE
015F 570 BISL #MCHK$M_MCK!MCHK$M_NEXM,-4(AP) ;SET TYPE FOR PRCTEST
0163 571
0163 573 ; Add check for read of BRRVR register in UBA. If this machine check
0163 574 ; is the result of a BRRVR read, then just REI. Someone will either loose
0163 575 ; a character from a terminal, or a device timeout will result. This is
0163 576 ; better than a system crash.
0163 577
0163 578 MOVL G^IOCSGL_ADPLIST,R0 ;POINT TO ADP LIST
016A 579 5$: BEQL 25$ ;DONE IF NOTHING LEFT ON LIST
016C 580 CMPW ADPSW_ADPTYPE(R0),#ATS_UBA ;IS THIS ADP FOR A UBA?
0172 581 BNEQ 20$ ;NO, LOOK AT REST OF LIST
0174 582 MOVL #3,R1 ;LOOK AT VA'S OF ALL 4 BRRVR REGISTERS
0177 583 10$: ADDL3 #9,ADPSL_UBASCB(R0)[R1],R2 ;CALCULATE ADDRESS OF BRRVR FROM
017D 584 ;THE SCB VECTOR ADDRESS SAVED IN THE ADP
017D 585 ; ***** NOTE ***** THE PREVIOUS INSTRUCTION ASSUMES THE CURRENTLY USED CODING
017D 586 ; SEQUENCE FOR DISPATCHING UBA INTERRUPTS IN THE MODULE INIADP.MAR. ANY
017D 587 ; CHANGES TO THAT CODE MY AFFECT THIS ROUTINE. THE ASSUMPTIONS ARE THAT THE
017D 588 ; VIRTUAL ADDRESS OF THE UBA BRRVR REGISTER IS AT AN OFFSET OF 10. BYTES PAST
017D 589 ; THE INTERRUPT VECTOR ADDRESS (9 IS ADDED TO THE SCB VECTOR VALUE BECAUSE
017D 590 ; THE VECTOR HAS BIT 0 SET TO INDICATE HANDLING THE INTERRUPT ON THE INTERRUPT
017D 591 ; STACK), THAT THE PC OF THE INSTRUCTION ACCESSING BRRVR IS 3 BYTES PAST THE
017D 592 ; INTERRUPT VECTOR ENTRY, AND THAT R4 AND R5 HAVE BEEN PUSHED ONTO THE STACK.
017D 593
017D 594 CMPL (R2),MCL_VA(AP) ;SAME VA AS IN MACHINE CHECK STACK?
0181 595 BNEQ 15$ ;BRANCH IF NOT BRRVR REFERENCE
0183 596 SUBL #<9-3>,R2 ;ELSE BACK UP TO PC OF INSTRUCTION
0186 597 ; IN UB INTERRUPT SERVICE THAT READS BRRVR
0186 598 CMPL R2,MCL_PC(AP) ;DOES IT MATCH PC IN MCHECK STACK?
018A 599 BEQL 30$ ;BRANCH IF SO, DEFINITELY CAME FROM
018C 600 ; UB INTERRUPT SERVICE.
018C 601 15$: SOBGEQ R1,10$ ;LOOP THROUGH ALL 4
018F 602 20$: MOVL ADPSL_LINK(R0),R0 ;FOLLOW ADP LIST TO END
0193 603 BRB 5$
0195 604 25$:
0195 605
0195 607 PUSHL W^GL CPTIMOUT ;WE ONLY KEEP TRACK OF ONE TIMEOUT
0199 608 MFPR #PR780$ TODR,W^GL CPTIMOUT ;UPDATE THAT HISTORY
019E 609 CMPL (SP)+,W^GL_CPTIMOUT ;ARE TIMEOUTS LESS THAN 10 MS APART?
01A3 610 BNEQ BRESUM ;BRANCH IF NOT TO TRY AND CONTINUE
01A5 611 BRW AMPUTATE ;OTHERWISE SOMETHING IS VERY WRONG
01A8 612
01A8 614 ; This machine check was a CPU timeout caused by a read of the BRRVR register
01A8 615 ; in the UBA. Log the error as a machine check, clean up the stack and REI.
01A8 616 ; This ignores the interrupt.
01A8 617
01A8 618 ; ***** WHAT IS THE 'REAL' STATE OF THE UBA AT THIS POINT? *****
01A8 619
01A8 620 30$: MOVW #EMBSK_MC,R3 ;LOG THE ERROR AS A MACHINE CHECK
01AB 621 BSBW LOGGR
01AE 622 POPR #^M<R0,R1,R2,R3,R4,R5,AP> ;RESTORE SAVED REGISTERS
01B2 623 ADDL #8,SP ;CLEAR PRCTEST STUFF FROM STACK
01B5 624 ADDL (SP)+,SP ;CLEAR MACHINE CHECK FRAME FROM STACK
01B8 625 ADDL #8,SP ;CLEAR MACHINE CHECK PC,PSL FROM STACK
```

MCHECK780  
V04-000

I 10  
- MACHINE CHECK EXCEPTION HANDLER FOR 11 16-SEP-1984 00:43:58 VAX/VMS Macro V04-00 Page 14  
CP TIMEOUT / SBI ERROR CONFIRMATION 5-SEP-1984 04:10:29 [SYSLOA.SRC]MCHECK780.MAR;1 (11)

54	8E	7D	01BB	626	MOVQ	(SP)+,R4	
		02	01BE	627	REI		;R4 AND R5 SAVED BY UBA INT DESPATCHER
			01BF	628			;REI ON THE UBA INTERRUPT PC,PSL



```
01BF 631 .SBTTL READ DATA SUBSTITUTE ERROR
01BF 632
01BF 633 .ENABL LSB
01BF 634 READSUBST:
33 0028'CF DA 01BF 635 MTPR W*GL CHSTATE,#PR780$-SBINT ;REENABLE CACHE
FC AC 02 C8 01C4 636 BLSL #MCHK$M MCK,-4(AP) ;SET MACHINE CHECK TYPE FOR PRTCTEST
51 2C AC DE 01C8 637 MOVAL MCL PC(AP),R1 ;SET POINTER TO PC,PSL
53 08 D0 01CC 638 MOVL #EMBSK HE,R3 ;SET HARD MEMORY ERROR TYPE
0290 30 01CF 639 BSBW LOG ERROR MEM ;LOG MEMORY ERROR
7E 30 AC 05 10 EF 01D2 643 EXTZV #PS$V IPL,#PSL$S IPL,MCL PSL(AP),-(SP) ;GET IPL WE WERE AT
02 8E D1 01D8 644 CMPL (SP)+,#IPL$-ASTDEC ;ARE WE AT A NON-PAGEABLE PRIORITY?
51 14 01DB 645 BGTR BAMPUTATE ;ABORT - RECOVERY IS USELESS
52 10 AC D0 01DD 646 MOVL MCL VA(AP),R2 ;GET VIRTUAL ADDRESS OF ERROR
54 00000000'GF D0 01E1 647 MOVL G*SCH$GL CURPCB,R4 ;CURRENT USER'S PCB ADDRESS
55 6C A4 D0 01E8 648 MOVL PCB$SL PHD(R4),R5 ;CURRENT USER'S PROCESS HEADER ADDRESS
00000000'GF 16 01EC 649 JSB G*MMG$SVAPTECHK ;TURN VA INTO VA OF PTE
50 63 D0 01F2 650 MOVL (R3),R0 ;GET THE PTE WHICH MAPS THE BAD PAGE
03 19 01F5 651 BLSS 5$ ;BRANCH IF PAGE VALID
00C4 31 01F7 652 BRW RDSNONRES ;ELSE FATAL ERROR
30 50 15 E0 01FA 653 5$:
50 50 15 00 EF 01FE 654 BBS #PTESV WINDOW,R0,BAMPUTATE ;BR IF PAGE IS PFN-MAPPED
00000000'GF 50 D1 0203 655 ASSUME PTESV PFN EQ 0
22 1A 020A 656 EXTZV #PTESV PFN,#PTES$ PFN,R0,R0 ;ISOLATE PAGE FRAME NUMBER IN PTE
7E 00000000'GF D0 020C 657 CMPL R0,G*MMG$GL_MAXPFN ;IS THERE PFN DATA BASE FOR PAG?
9E40 20 88 0213 658 BGTRU BAMPUTATE ;BR IF NO PFN DATA BASE FOR PAGE
51 D4 0217 659 MOVL G*PFNSAB TYPE,-(SP) ;PFN TYPE ARRAY ADDRESS *****
04 63 1A E5 0219 660 BISB #PFNSM_BADPAG,@(SP)+[R0] ;MARK PAGE BAD *****
51 80 8F 9A 021D 661 CLRL R1 ;CLEAR MODIFY BIT PROPAGATOR
7E 00000000'GF D0 0221 662 BBCC #PTESV_MODIFY,(R3),10$ ;TEST (& CLEAR) MODIFY BIT IN PTE
9E40 51 88 0228 663 MOVZBL #PFNSM_MODIFY,R1 ;SET MODIFY PROPAGATOR
10$:
MOVL G*PFNSAB STATE,-(SP) ;ADDRESS OF PFN STATE ARRAY *****
BISB R1,@(SP)+[R0] ;PROPAGATE MODIFY BIT TO PFN DATABASE **
022C 666 ASSUME PFNSM_MODIFY EQ 12B
022C 667
022C 668
03 14 022C 669 BGTR 15$ ;PAGE NOT MODIFIED - HE'S OK
022E 670 BAMPUTATE:
04 AC 01F0 8F B3 0231 671 BRW AMPUTATE
FE86 31 022E 672 15$:
04 AC 08 93 0237 673 BITW #*X1F0,MCL_SUMMARY(AP) ;WAS ERROR FAULT OR ABORT?
0A 12 0239 674 BNEQ BAMPUTATE ;ABORT - DON'T TRY ANY REPAIRS
7E 2C BC 9A 023D 675 BITB #8,MCL_SUMMARY(AP) ;IS ERROR IB ERROR FAULT
E5 070D'CF 8E E1 0243 676 BNEQ 20$ ;BRANCH IF YES, IB ERRORS RESUME
7E 00000000'GF D0 0249 677 MOVZBL @MCL PC(AP),-(SP) ;GET OPCODE FOR RESTARTABILITY CHECK
01 9E40 D8 1A 0254 678 20$:
01 9E40 03 00 EC 0256 679 BBC (SP)+,W*RESUMABLE,BAMPUTATE ;BRANCH IF INST NOT RESUMABLE
025D 680 MOVL G*PFNSAW REFCNT,-(SP) ;ADDRESS OF PFN REFCNT ARRAY *****
0263 681 CMPW @(SP)+[R0],#1 ;CHECK FOR I/O IN PROGRESS, ETC. ***
0263 682 BGTRU BAMPUTATE ;IF SO, DON'T TRY ANYTHING FANCY
0263 683 MOVL G*PFNSAB TYPE,-(SP) ;ADDRESS OF PFN TYPE ARRAY *****
0263 684 CMPV #PFNSV_PAGTYP,#PFNS$S_PAGTYP,@(SP)+[R0],#PFNSC_SYSTEM ;****
0263 685 ;CHECK FOR SYSTEM OR GLOBAL PAGE
0263 686 ASSUME PFNSC_SYSTEM EQ 1 ;CHECK TYPE OF PAGE
0263 687 ASSUME PFNSC_PROCESS EQ 0
C9 1A 0263 688 BGTRU BAMPUTATE ;BRANCH IF GLOBAL PAGE
0263 689
0263 690 ; IN THE FUTURE WE MAY RECOVER FROM HARD ECC ERRORS ON GLOBAL PAGES
```

```
0265 691 ; AS WELL, BUT FOR NOW WE ABORT THE IMAGE.
0265 692
0265 693
54 00000000'GF 52 D5 0265 694 30$: TSTL R2 ;CHECK THE VIRTUAL ADDRESS
0B 14 0267 695 BGTR 40$ ;BRANCH IF PAGE IS PROCESS PRIVATE
55 6C A4 9E 0269 696 MOVAB G^MMGSAL SYSPCB,R4 ;SYSTEM PAGES ARE KEPT TRACK OF IN
00 63 1F E5 0270 697 MOVL PCB$P.PHD(R4),R5 ;A WORKING SET LIST IN THE SYSTEM PCB
7E 00000000'GF D0 0274 698 40$: BBCC #PTESV_VALID,(R3),50$ ;CLEAR VALID BIT FROM PTE
9E40 B7 0278 699 50$: INVALID R2 ;INVALIDATE TRANSLATION BUFFER OF VA
06 18 027B 700 MOVL G^PFNSAW REF CNT,-(SP) ;ADDRESS OF PFN REF CNT ARRAY *****
7E 00000000'GF D0 0282 701 DECW @ (SP)+[R0] ;REDUCE REFERENCE COUNT TO 0 *****
06 18 0285 702 BGEQ 60$
00000000'GF 16 0287 703 JSB G^MMGSREFCNTNEG
00000000'GF D0 028D 704 60$: MOVL G^PFNSAX WSLX,-(SP) ;ADDRESS OF PFN WSLX ARRAY *****
0294 705 PFN REFERENCE
0294 706 MOVZWL <@ (SP)+[R0],R1>,- ;GET WORKING-SET LIST INDEX FOR PAGE **
0294 707 LONG OPCODE=MOVL,-
0294 708 IMAGE=SYSLOA780.EXE
00000000'GF 16 02A6 709 JSB G^MMGSDELWSLEX ;DELETE IT FROM THE WORKING SET ITS IN
00000000'GF 16 02AC 710 JSB G^MMGSDELCONPFN ;DELETE PAGE FROM PAGE TABLE
52 02 9A 02B2 711 MOVZBL #PFNSC BADPAGLST,R2 ;SET UP LIST TO PUT PAGE ON
00000000'GF 16 02B5 712 JSB G^MMGSINSPFNT ;PUT PAGE ONTO BAD PAGE LIST
02BB 713
02BB 714 ; AT THIS POINT, THE PTE FOR THE BAD PAGE CONTAINS ITS MASS STORAGE
02BB 715 ; ADDRESS. THIS WILL CAUSE A FRESH COPY OF THE PAGE TO BE FETCHED WHEN
02BB 716 ; THE PROCESS IS RESUMED.
02BB 717
FDDA 31 02BB 718 BRW RESUME ;LOG MACHINE CHECK AND RESUME PROCESS
02BE 719
02BE 720 RDSNONRES:
02BE 721
02BE 722 POPR #^M<R0,R1,R2,R3,R4,R5,AP>
103F 8F BA 02BE 722 JSB G^EXESMCHK BUGCHK ;RECOVERY BLOCK IN EFFECT?
00000000'GF 16 02C2 723 BUG_CHECK RDSNONRES,FATAL ;READ DATA SUBSTITUTE PAGE NONRESIDENT
02C8 724
02CC 725
02CC 726
02CC 727 .DSABL LSB
```

```

02CC 730 .SBTTL INTERFACE FROM MACHINE CHECK HANDLER TO ERROR LOGGER
02CC 731 :++
02CC 732 :   LOGGERS - Routine to log Machine Check interrupts and aborts
02CC 733 :
02CC 734 :   INPUTS:
02CC 735 :
02CC 736 :       R3 - Error log type
02CC 737 :       AP - Pointer to Machine Check error log frame
02CC 738 :       -4(AP) - MASK FOR PRCTEST
02CC 739 :       -8(AP) - PC,PSL POINTER FOR PRCTEST
02CC 740 :
02CC 741 :   OUTPUTS:
02CC 742 :
02CC 743 :       Entry made in error log conditional on PRCTEST
02CC 744 :       R0-R5 destroyed
02CC 745 :   --
02CC 746 :
02CC 747 :   LOGGERS:
02CC 748 :       ADDL3   MCL_COUNT(AP),#<2*4>,R4 ;GET SIZE OF ENTRY IN BYTES
02CC 749 :       MOVAB   MCL_SUMMARY(AP),R5 ;GET ADDRESS OF ENTRY
02CC 750 :       MOVQ    -8(AP),R1 ;GET MASK AND PC POINTER FOR PRCTEST
02CC 751 :       JSB     G^EXESMCHK_TEST ;ARE WE TO LOG THIS ERROR?
02CC 752 :       BLBS    R0,10$ ;NO, RECOVERY BLOCK IGNORES IT
02CC 753 :       INCL    G^EXESGL_MCHKERRS ;KEEP COUNT OF MACHINE CHECKS
02CC 754 :       10$: ;FALL THROUGH TO 'LOGIT'
02CC 755 :
02CC 756 :   :++
02CC 757 :   :   LOGIT - INTERFACE TO SYSTEM ERROR LOG
02CC 758 :   :
02CC 759 :   :   INPUTS:
02CC 760 :   :
02CC 761 :   :       R1 = PC,PSL POINTER FOR PRCTEST
02CC 762 :   :       R2 = MASK FOR PRCTEST
02CC 763 :   :       R3 = ERROR LOG TYPE
02CC 764 :   :       R4 = SIZE OF LOG ENTRY IN BYTES
02CC 765 :   :       R5 = ADDRESS OF LOG ENTRY
02CC 766 :   :       (SP) = RETURN ADDRESS
02CC 767 :   :   --
02CC 768 :   :
02CC 769 :   :   .ENABL   LSB
02CC 770 :   :
02CC 771 :   :   LOGIT:
02CC 772 :   :
02CC 773 :   :       MFPR   #PR780$ SBIFS,R0 ;GET SBI FAULT/STATUS REGISTER
02CC 774 :   :       BBCC   #SBIFSS$ NEF,R0,10$ ;CLEAR NESTED ERROR FLAG
02CC 775 :   :       10$: MTPR   R0,#PR780$ SBIFS ;WRITE IT BACK TO CLEAR SILO LOCK
02CC 776 :   :       AND    #PR780$ SBIFS,R0 ;AND FAULT LATCH
02CC 777 :   :       MFPR   #PR780$ SBIER,R0 ;GET SBI ERROR REGISTER
02CC 778 :   :       BISW   #SBIERSM_IBTO!SBIERSM_IBRDS!SBIERSM_CPTO!SBIERSM_RDS!-
02CC 779 :   :       SBIERSM_CRD,R0 ;SET BITS FOR ERRORS WE'RE HANDLING
02CC 780 :   :       MTPR   R0,#PR780$ SBIER ;WRITE IT BACK TO CLEAR LATCHES
02CC 781 :   :
02CC 782 :   :       JSB     G^EXESMCHK_TEST ;ARE WE TO LOG THIS ERROR?
02CC 783 :   :       BLBS    R0,20$ ;NO, RECOVERY BLOCK IGNORES IT
02CC 784 :   :
02CC 785 :   :   MCHK$GL_LOG::
02CC 786 :   :
02CC 787 :   :       ADDL3   #EMBSB_MC_SUMCOD,R4,R1 ;ADD SPACE FOR HEADER FOR BUFFER SIZE
02CC 788 :   :
02CC 789 :   :
02CC 790 :

```



00000000'GF	16	0309	792	JSB	G*ERL\$ALLOCEMB	;GET AN ERROR LOGGING BUFFER
		030F	796			
14 50	E9	030F	797	BLBC	R0,20\$	;BRANCH IF DIDN'T GET IT
52	DD	0312	798	PUSHL	R2	;SAVE ADDRESS OF ERROR LOG BUFFER
04 A2 53	B0	0314	799	MOVW	R3,EMBSW_MC_ENTRY(R2)	;SET ENTRY TYPE TO FAULT TYPE
10 A2 65 54	28	0318	800	MOVC3	R4,(R5),EMBSB_MC_SUMCOD(R2)	;IN ONE SWELL FOOP...
52 BE	D0	031D	801	MOVL	(SP)+,R2	;GET POINTER TO BUFFER START IN R2
00000000'GF	16	0320	802			
		0320	804	JSB	G*ERL\$RELEASEMB	;INDICATE BUFFER READY TO LOG
		0326	808			
	05	0326	809	RSB		;EXIT WITH HARDWARE LOG STILL ON STACK
		0327	810			
		0327	811	.DSABL	LSB	

```
0327 813
0327 814 .SBTTL SBI ERROR INTERRUPTS
0327 815 :++
0327 816 : Handle SBI Faults and Asynchronous Write Timeouts on the SBI.
0327 817
0327 818 SBI Fault:
0327 819 : Log the error; try to resume normal execution.
0327 820
0327 821 Asynchronous Write Timeouts:
0327 822 : Log the error.
0327 823 : Set up a "fake" machine check log on the stack. This is so we
0327 824 : can share the exception exit path (REFLECTCHK) that machine checks
0327 825 : take if the current process is executing in USER or SUPER mode.
0327 826 : If the current process is in EXEC or KERNEL mode, bugcheck.
0327 827 :--
0327 828 .ALIGN LONG ;THIS IS VECTORED TO
0328 829 GBLDEF INT5C ;SBI FAULT VECTOR
0328 830 GBLDEF LOGSBF
0328 831 SETIPL #*X1F ;DISABLE ALL INTERRUPTS
00FF 8F BB 032B 832 PUSHF #*M<R0,R1,R2,R3,R4,R5,R6,R7> ;SAVE SOME WORK REGS
53 04 9A 032F 833 MOVZBL #EMBSK BE,R3 ;ERROR LOG TYPE
52 03 D0 0332 834 MOVL #MCHK$M_MCK!MCHK$M_LOG,R2 ;MASK FOR PRCTEST
00FF 8F BA 0335 835 BSBB LOGSBI ;USE SAME CODE AS ASYNC WRITE FAILURE
02 0337 836 POPR #*M<R0,R1,R2,R3,R4,R5,R6,R7> ;RESTORE R0-R7
033B 837 REI ;TRY TO CONTINUE
033C 838
033C 839 .ALIGN LONG ;THIS IS VECTORED TO
033C 840 GBLDEF INT60 ;ASYNCHRONOUS WRITE TIMEOUT
033C 841 GBLDEF LOGAWE
033C 842 SETIPL #*X1F ;DISABLE ALL INTERRUPTS
00FF 8F BB 033F 843 PUSHF #*M<R0,R1,R2,R3,R4,R5,R6,R7> ;SAVE SOME WORK REGS
53 07 9A 0343 844 MOVZBL #EMBSK AW,R3 ;ERROR LOG TYPE
52 07 D0 0346 845 MOVL #MCHK$M_LOG!MCHK$M_MCK!MCHK$M_NEXM,R2 ;PRCTEST MASK
00FF 8F BA 034B 846 BSBB LOGSBI ;USE SAME CODE AS SBI FAULT ERROR
5E 28 C2 034F 847 POPR #*M<R0,R1,R2,R3,R4,R5,R6,R7> ;RESTORE R0-R7
28 DD 0352 848 SUBL #40,SP ;ALLOCATE FAKE MACHINE CHECK FRAME
07 DD 0354 849 PUSHL #40 ;SIZE OF FRAME
30 AE DF 0356 850 PUSHL #MCHK$M_MCK!MCHK$M_LOG!MCHK$M_NEXM
103F BF BB 0359 851 PUSHAL MCL PC+4(SP) ;MASK AND PC,PSL FOR PRCTEST
5C SE 24 C1 035D 852 PUSHF #*M<R0,R1,R2,R3,R4,R5,AP> ;SAVE REGISTERS FOR COMMON CODE
0003'CF A0 8F 93 0361 853 ADDL3 #<9*4>,SP,AP ;POINT AP TO FAKE MACHINE CHECK FRAME
0367 854 BITB #B10100000,W^GL_CSBITA+3 ;WAS WRITE IN USER OR SUPERVISOR
03 12 0367 855 BNEQ 10$ ;MODE AND NOT UPDATING A PAGE TABLE
FD64 31 0367 856 BRW REFLECTCHK ;IF NOT, MUST BUGCHECK
036C 857 10$: ;BRANCH IF OK TO CONTINUE
103F 8F BA 036C 858 POPR #*M<R0,R1,R2,R3,R4,R5,AP>
00000000'GF 16 036C 859 JSB G^EXE$MCHK BUGCHK ;RECOVERY BLOCK IN EFFECT?
0376 861 BUG_CHECK ASYNCRTER,FATAL ;WRITE ERROR IN KERNAL OR EXEC MODE
037A 862 ;OR WHILE UPDATING PAGE TABLE
037A 863
```

```
037A 868 :++
037A 869 :LOGSBI -- Subroutine to log SBI errors.
037A 870 :
037A 871 :Implicit Inputs:
037A 872 :
037A 873 :+-----+
037A 874 :| return address | : (SP)
037A 875 :+-----+
037A 876 :| saved
037A 877 :| R0 - R7
037A 878 :+-----+
037A 879 :| interrupt PC
037A 880 :+-----+
037A 881 :| interrupt PSL
037A 882 :+-----+
037A 883 :
037A 884 :Create an SBI error log buffer that contains:
037A 885 :The contents of the configuration register of every
037A 886 :SBI adapter on the bus or 0 (16 longwords).
037A 887 :A copy of the SBI silo (16 longwords).
037A 888 :SBI processor registers SBITA, SBIER, SBIMT, SBISC, and SBIFS.
037A 889 :--
037A 890 :LOGSBI:
037A 891 :JSB G^EXE$MCHK_TEST ;LOG SBI ERROR
037A 892 :BLBS R0,5$ ;ARE WE TO LOG THIS ERROR?
037A 893 :INCL G^EXE$GL_MCHKERRS ;NO, RECOVERY BLOCK IGNORES IT
037A 894 :5$: ;KEEP COUNT OF MACHINE CHECKS
037A 895 :MOVQ <9*4>(SP),-(SP) ;MAKE A SECOND COPY OF PC,PSL
037A 896 :MOVL G^EXE$GL_CONFREGL,R7 ;ARRAY OF NEXUS DEVICE TYPE CODES
037A 897 :MOVL G^MMG$GL_SBICONF,R5 ;ARRAY OF ADAPTER VA'S
037A 898 :MOVL #15,R0 ;INDEX OF LAST POSSIBLE ITEM ON SBI
037A 899 :10$: CLRL -(SP) ;ASSUME NO ADAPTOR HERE
037A 900 :MOVL (R5)[R0],R1 ;GET VA OF CONTROLLER/ADAPTER
037A 901 :BGEQ 20$ ;GEQ IMPLIES NO VALID SYSTEM VA.
037A 902 :TSTL (R7)[R0] ;TEST ADAPTER TYPE (ONLY WORKS FOR SBI)
037A 903 :BEQL 20$ ;IF EQL, NO ADAPTOR HERE
037A 904 :MOVL (R1),(SP) ;STORE ADAPTOR CSRO ON STACK
037A 905 :20$: SOBGEQ R0,10$ ;LOOP THRU ALL POSSIBLE 16
037A 906 :MOVL #15,R0 ;SET UP COUNT OF NUMBER OF TIMES TO
037A 907 :30$: MFPR #PR780$_SBIS,-(SP) ;READ SILO
037A 908 :SOBGEQ R0,30$ ;SAVE INFORMATION FOR ERROR LOGGER
037A 909 :MFPR #PR780$_SBITA,-(SP) ;LOOP THRU ALL 16
037A 910 :MCOML (SP),W^GL_CSBITA ;SAVE SBI TIMEOUT REGISTER
037A 911 :MFPR #PR780$_SBIER,-(SP) ;SAVE SBI ERROR REGISTER
037A 912 :MFPR #PR780$_SBIMT,-(SP) ;SAVE SBI MAINTENANCE REGISTER
037A 913 :MFPR #PR780$_SBISC,-(SP) ;SAVE SBI SILO COMPARATOR
037A 914 :MFPR #PR780$_SBIFS,-(SP) ;SAVE SBI FAULT/STATUS REGISTER
037A 915 :MOVZWL #<16*4>+<16*4>+<7*4>,-(SP) ;SAVE NUMBER OF BYTES OF ENTRY
037A 916 :
037A 917 :MOVAL <<16*4>+<16*4>+<6*4>>(SP),R1 ;ADDRESS OF PC,PSL FOR PRICTEST
037A 918 :MOVL (SP),R4 ;# OF BYTES TO LOG
037A 919 :MOVAB 4(SP),R5 ;ADDRESS OF LOG ENTRY
037A 920 :BSBW LOGIT ;CALL ERROR LOGGER
037A 921 :ADDL (SP)+,SP ;CLEAN STACK OF LOG AND FAKE PC,PSL
037A 922 :RSB ;RETURN
037A 923 :
037A 924 :
037A 925 :
037A 926 :
037A 927 :
037A 928 :
037A 929 :
037A 930 :
037A 931 :
037A 932 :
037A 933 :
037A 934 :
037A 935 :
037A 936 :
037A 937 :
037A 938 :
037A 939 :
```

00000000'GF 16 037A 896 JSB G^EXE\$MCHK\_TEST ;LOG SBI ERROR  
06 50 E8 0380 897 BLBS R0,5\$ ;ARE WE TO LOG THIS ERROR?  
00000000'GF D6 0383 899 INCL G^EXE\$GL\_MCHKERRS ;NO, RECOVERY BLOCK IGNORES IT  
7E 24 AE 7D 0389 900 5\$: ;KEEP COUNT OF MACHINE CHECKS  
57 00000000'GF D0 0389 901 MOVQ <9\*4>(SP),-(SP) ;MAKE A SECOND COPY OF PC,PSL  
55 00000000'GF D0 038D 902 MOVL G^EXE\$GL\_CONFREGL,R7 ;ARRAY OF NEXUS DEVICE TYPE CODES  
50 0F D0 0394 903 MOVL G^MMG\$GL\_SBICONF,R5 ;ARRAY OF ADAPTER VA'S  
7E 7E D4 039B 904 MOVL #15,R0 ;INDEX OF LAST POSSIBLE ITEM ON SBI  
51 6540 D0 039E 905 10\$: CLRL -(SP) ;ASSUME NO ADAPTOR HERE  
08 18 03A0 906 MOVL (R5)[R0],R1 ;GET VA OF CONTROLLER/ADAPTER  
6740 D5 03A4 907 BGEQ 20\$ ;GEQ IMPLIES NO VALID SYSTEM VA.  
03 13 03A6 908 TSTL (R7)[R0] ;TEST ADAPTER TYPE (ONLY WORKS FOR SBI)  
6E 61 D0 03A9 909 BEQL 20\$ ;IF EQL, NO ADAPTOR HERE  
ED 50 F4 03AB 919 MOVL (R1),(SP) ;STORE ADAPTOR CSRO ON STACK  
50 0F D0 03AE 920 20\$: SOBGEQ R0,10\$ ;LOOP THRU ALL POSSIBLE 16  
7E 31 DB 03B1 921 MOVL #15,R0 ;SET UP COUNT OF NUMBER OF TIMES TO  
FA 50 F4 03B4 922 30\$: MFPR #PR780\$\_SBIS,-(SP) ;READ SILO  
7E 35 DB 03B7 923 SOBGEQ R0,30\$ ;SAVE INFORMATION FOR ERROR LOGGER  
0000'CF 6E D2 03B8 924 MFPR #PR780\$\_SBITA,-(SP) ;LOOP THRU ALL 16  
7E 34 DB 03BD 925 MCOML (SP),W^GL\_CSBITA ;SAVE SBI TIMEOUT REGISTER  
7E 33 DB 03C2 926 MFPR #PR780\$\_SBIER,-(SP) ;SAVE SBI ERROR REGISTER  
7E 32 DB 03C5 927 MFPR #PR780\$\_SBIMT,-(SP) ;SAVE SBI MAINTENANCE REGISTER  
7E 30 DB 03C8 928 MFPR #PR780\$\_SBISC,-(SP) ;SAVE SBI SILO COMPARATOR  
7E 009C 8F 3C 03CB 929 MFPR #PR780\$\_SBIFS,-(SP) ;SAVE SBI FAULT/STATUS REGISTER  
51 0098 CE DE 03CE 931 MOVZWL #<16\*4>+<16\*4>+<7\*4>,-(SP) ;SAVE NUMBER OF BYTES OF ENTRY  
54 6E D0 03D3 932 MOVAL <<16\*4>+<16\*4>+<6\*4>>(SP),R1 ;ADDRESS OF PC,PSL FOR PRICTEST  
55 04 AE 9E 03D3 933 MOVL (SP),R4 ;# OF BYTES TO LOG  
FF05 30 03D8 934 MOVAB 4(SP),R5 ;ADDRESS OF LOG ENTRY  
5E 8E C0 03DB 935 BSBW LOGIT ;CALL ERROR LOGGER  
05 03E2 936 ADDL (SP)+,SP ;CLEAN STACK OF LOG AND FAKE PC,PSL  
03E5 937 RSB ;RETURN  
03E6 938  
03E6 939



```

                                .SBTTL MEMORY TIMER SCAN
03E6 941
03E6 942
03E6 944 ECC$REENABLE::                                ; Define timer scan entry point.
03E6 948
0022'CF B7 03E6 949 DECW W^GW_WATCH                                ; Count seconds down.
19 14 03EA 950 BGTR REENABLE_INTS                                ; Br if time hasn't elapsed yet.
03EC 951
03EC 952 ; Scan all memory controllers for unreported errors. This will yield a
03EC 953 ; representative sample of memory errors in the error log, even if CRD
03EC 954 ; interrupts are disabled.
03EC 955
0022'CF 3C B0 03EC 956 MOVW #SOMETIME,W^GW_WATCH                ; Reset time interval.
0A BB 03F1 957 PUSHR #^M<R1,R3>                                ; Save working registers.
7E DC 03F3 958 MOVPSL -(SP)                                ; Set up interrupt PSL.
00 10 03F5 959 BSBB 10$                                ; Fake interrupt PC on stack.
51 6E DE 03F7 960 10$: MOVAL (SP),R1                        ; Point to exception PC,PSL.
53 06 D0 03FA 961 MOVL #EMB$K_SE,R3                        ; Log soft memory errors.
0062 30 03FD 962 BSBW LOG_ERROR_MEM                        ; Scan all memory controllers, and
SE 08 C0 0400 963 ; log any that report errors.
0A BA 0403 964 ADDL #8,SP                                    ; Pop PC,PSL pair from stack.
0405 965 POPR #^M<R1,R3>                                ; Restore registers.
0405 966
0020'CF B7 0405 967 REENABLE_INTS:
2B 14 0409 968 DECW W^GW_REENAB                                ; Count seconds down.
0020'CF 0384 8F B0 040B 969 BGTR 10$                        ; Branch if reenab time not elapsed.
3F BB 0412 970 MOVW #REENABTIME,W^GW_REENAB                ; Reset the time interval.
0010'CF 10 00 00 8F 00 2C 0414 971 PUSHR #^M<R0,R1,R2,R3,R4,R5> ; Save working registers.
00000000'GF 00' E1 041D 972 MOVCS #0,#0,#0,#16,W^AB_MEMERR ; Reset 16 bytes of error count to 0.
55 00000000'GF D0 0425 973 BBC S^#EXESV_CRDENABL, - ; Branch if SYSGEN parameter specifies
53 0000'CF DE 042C 974 G^#EXESGL_FLAGS,5$                ; no CRD interrupts.
008C 30 0431 975 MOVL G^MMG$GL_SBICONF,R5                ; Get addr of SBICONF for action routines.
3F BA 0434 976 MOVAL W^ENAB_ROUTINES,R3                ; Array of action routine vectors.
05 0436 977 BSBW LOCATE_MEM                                ; Locate mem and call action routines
978 ; to re-enable CRD interrupts.
979 5$: POPR #^M<R0,R1,R2,R3,R4,R5> ; Restore registers.
980 10$: RSB

```

```

                                .SBTTL Memory Error Interrupts
                                :
                                : SBI Alert interrupts are vectored here.
                                :
                                : .ALIGN LONG
                                :
                                : GBLDEF INT58 ; EXE$INT58:: or MPSS$INT58::
                                : GBLDEF LOGSBA ; EXE$LOGSBA:: or MPSS$LOGSBA::
                                :
                                : Save some registers.
                                : Disable all interrupts.
                                : Set pointer to interrupt PC,PSL.
                                : Set SBI Alert error log type.
                                : Log memory controller registers.
                                : Restore registers.
51 0A BB 0437 982
    08 AE DE 0437 983
    53 05 DO 0437 984
    001B 30 0437 985
    0A BA 0437 986
    02 0437 987
    0438 988
    0438 989
    0438 990
    043A 991
    043D 992
    0441 993
    0444 994
    0447 995
    0449 996
    044A 997
    044A 998
    044A 999
    044A 1000
    044A 1001
    044C 1002
    044C 1003
    044C 1004
    044C 1005
    044E 1006
    0451 1007
    0455 1008
    0459 1009
    045C 1010
    045F 1011
    02 0461 1012

                                .ALIGN LONG
                                :
                                : GBLDEF INT54 ; EXE$INT54:: or MPSS$INT54::
                                : GBLDEF LOGCRD ; EXE$LOGCRD:: or MPSS$LOGCRD::
                                :
                                : Save some registers.
                                : Disable all interrupts.
                                : Keep count of these errors.
                                : Set pointer to interrupt PC,PSL.
                                : Set soft memory error type.
                                : Log memory controller registers.
    0A BB 044C 1005
    0024 CF D6 044E 1006
    51 08 AE DE 0451 1007
    53 06 DO 0455 1008
    0003 30 0459 1009
    0A BA 045C 1010
    02 045F 1011
    0461 1012

                                PUSH R1,R3
                                SETIPL #X1F
                                MOVAL 8(SP),R1
                                MOVL #EMBSK_SA,R3
                                BSBW LOG_ERROR, MEM
                                POPR #MZR1,R35
                                REI

```

```
0462 1014 .SBTTL LOGMEM Master Routine
0462 1015 :++
0462 1016 :
0462 1017 : FUNCTIONAL DESCRIPTION:
0462 1018 : This routine is called to build an errorlog containing the device
0462 1019 : registers of the memory controllers on an 11/780 system. If called
0462 1020 : at the LOG_ERROR_MEM entry point, it will scan the memory controller
0462 1021 : status registers, and only log those controllers which report errors.
0462 1022 : If called at the LOG_ALL_MEM entry point, it will unconditionally log
0462 1023 : all memory controllers on the system.
0462 1024 :
0462 1025 : INPUTS:
0462 1026 : R1 - pointer to exception PC,PSL
0462 1027 : R3 - Error log type code (e.g. EMBSK_type)
0462 1028 :
0462 1029 : OUTPUTS:
0462 1030 : Format of error log:
0462 1031 : # of memory controllers logged
0462 1032 : memory type-specific log #1
0462 1033 : memory type-specific log #2
0462 1034 :
0462 1035 :
0462 1036 : PC of instruction at fault time
0462 1037 : PSL at fault time
0462 1038 :
0462 1039 : All registers are preserved.
0462 1040 :
0462 1041 :--
0462 1042 :
0462 1043 LOG_ERROR_MEM:
0462 1044 POSHR #*M<R0,R1,R2,R3,R4,R5,R6,R7,R8,R9,R10,R11,AP> ; Log controllers with errors.
53 1FFF 8F BB 0466 1045 MOVAL W*LOGERR_ROUTINES,R3 ; Array of action routine vectors.
0000 CF DE 09 11 046B 1046 BRB LOGMEM ; Join common code.
046D 1047 :
046D 1048 LOG_ALL_MEM:
046D 1049 POSHR #*M<R0,R1,R2,R3,R4,R5,R6,R7,R8,R9,R10,R11,AP> ; Unconditionally log all controllers.
53 1FFF 8F BB 0471 1050 MOVAL W*LOGALL_ROUTINES,R3 ; Array of action routine vectors.
0000 CF DE 0476 1051 :
0476 1052 LOGMEM:
0476 1053 CLRQ R5 ; Log memory controller registers.
55 7C 0476 1054 ; Zero error log byte count and number
0478 1055 MOVL G*MMG$GL SBICONF,R7 ; of controllers logged.
57 00000000 GF DO 0478 1056 MOVL #SS$_NORMAL,AP ; For use by action routines.
5C 01 DO 047F 1057 ; Assume no fatal memory errors.
0482 1058 :
0482 1059 : Locate all memory controllers on the SBI. When a memory controller is
0482 1060 : found, call the appropriate action routine to create that controller's
0482 1061 : portion of the common error log buffer on the stack.
003B 30 0482 1062 :
0485 1063 BSBW LOCATE_MEM
0485 1064 :
0485 1065 : The error log buffer has been built on the stack; SP points to the beginning.
0485 1066 : Add the number of memory controllers logged, then log the errors.
0485 1067 : Current register usage:
0485 1068 : R5 - Number of bytes in the error log.
0485 1069 : R6 - Number of memory controllers logged.
0485 1070 : SP - Points to the beginning of the error log buffer.
0485 1070 : AP - LBS if no fatal memory errors were discovered, else LBC.
```



				0485	1071 :				
51	6E45	9E		0485	1072 :	MOVAB	(SP)[R5], R1	:	Get address of saved R0 on stack.
53	OC A1	D0		0489	1073	MOVL	12(R1), R3	:	Restore input value of R3.
51	04 A1	D0		048D	1074	MOVL	4(R1), R1	:	Restore input value of R1.
	56	DD		0491	1075	PUSHL	R6	:	Add # of controllers to log buffer.
7E	55 04	C1		0493	1076	ADDL3	#<1*4>, R5, -(SP)	:	Total # bytes in error log buffer.
	55	D5		0497	1077	TSTL	R5	:	Were any memory registers logged?
	12	13		0499	1078	BEQL	10\$	:	No. Skip call to error logger.
00000000	'GF	D6		049B	1079	INCL	G^EXESGL_MEMERRS	:	Keep count of memory errors
54	6E	D0		04A1	1080	MOVL	(SP), R4	:	Use # bytes as input to LOGIT.
55	04 AE	DE		04A4	1081	MOVAL	4(SP), R5	:	Address of error log buffer.
	52	D4		04A8	1082	CLRL	R2	:	Always log memory errors.
	FE3A	30		04AA	1083	BSBW	LOGIT	:	Log the error.
SE	8E	C0		04AD	1084 10\$:	ADDL	(SP)+, SP	:	Remove error log buffer from stack.
	08 SC	E8		04B0	1085	BLBS	AP, 20\$	:	Bt if fatal error not signalled.
1FFF	BF	BA		04B3	1086	POPR	#^M<R0,R1,R2,R3,R4,R5,R6,R7,R8,R9,R10,R11,AP>	:	
				04B7	1088	BUG_CHECK	ASYNCRWITER,FATAL	:	Unrecoverable memory controller error.
				04BB	1092 20\$:				
1FFF	BF	BA		04BB	1093	POPR	#^M<R0,R1,R2,R3,R4,R5,R6,R7,R8,R9,R10,R11,AP>		
		05		04BF	1094	RSB			

```
04C0 1096 .SBTTL LOCATE_MEM Dispatching Routine
04C0 1097 ++
04C0 1098 Routine to locate memory controllers on 11/780 SBI.
04C0 1099
04C0 1100 FUNCTIONAL DESCRIPTION:
04C0 1101 This routine scans an array of adapter type codes that tell which
04C0 1102 adapters are attached to the SBI. When it finds a memory controller
04C0 1103 adapter, it dispatches to an action routine for that memory controller
04C0 1104 type.
04C0 1105
04C0 1106 INPUTS:
04C0 1107 R3 - address of action routine table; 1 action routine/memory controller
04C0 1108 Current format of action routine tables (the tables are created by the
04C0 1109 MEMORY_ROUTINES macro):
04C0 1110 (R3): self-relative offset to MS780C action routine
04C0 1111 4(R3): self-relative offset to MA780 action routine
04C0 1112 8(R3): self-relative offset to MS780E action routine
04C0 1113
04C0 1114 On entry to memory action routine:
04C0 1115 R0,R1 - local registers, not preserved across calls to action routines
04C0 1116 R2 - TR# of this memory controller
04C0 1117 R3 - not available to be used by action routines
04C0 1118 R4 - address of CONFREGL array (If the 780 ever gets a BI, code
04C0 1119 must change, because TSTL assumes no high-order bits set.)
04C0 1120 R5-AP - available; contents are preserved across calls to multiple
04C0 1121 action routines (i.e. can be used for global storage)
04C0 1122
04C0 1123 Note: an action routine may deposit a -1 in R2 to cause LOCATE_MEM
04C0 1124 to prematurely exit the memory scan loop (and not call any other
04C0 1125 memory action routines).
04C0 1126
04C0 1127 OUTPUTS:
04C0 1128 R0-R4 destroyed. (Other registers may be destroyed by action routines.)
04C0 1129 --
04C0 1130
04C0 1131 LOCATE_MEM:
04C0 1132 MOVL G^EXESGL_CONFREGL,R4 ; Get address of CONFREGL.
52 54 00000000'GF D0 04C7 1133 SUBL3 #1,G^EXESGL_NUMNEXUS,R2 ; Get index into nexus arrays.
00000000'GF 01 C3
04CF 1134
04CF 1135 : Loop through all nexuses. If a memory controller is found at any of the
04CF 1136 : nexus slots, then call the action routine associated with that memory.
04CF 1137
04CF 1138 10$: MOVL (R4)[R2],R1 ; Get nexus device type from CONFREGL.
51 6442 D0 04D3 1139 BEQL 20$ ; Not a memory; go to next nexus.
14 13 04D5 1140 LOCC R1,#MENTYPCNT,W^MENTYP ; Find type in memory type array.
0000'CF 12 51 3A 04DB 1141 ; R1 <- addr of type code (if found).
OC 13 04DB 1142 BEQL 20$ ; Not a memory; go to next nexus.
51 12 A1 9A 04DD 1143 MOVZBL MENTYPCNT(R1),R1 ; Use offset to get general memory type.
51 6341 DE 04E1 1144 MOVAL (R3)[R1],R1 ; Get self-relative address of action
00 B141 16 04E5 1145 JSB @ (R1)[R1] ; routine, and call it.
E3 52 F4 04E9 1146 20$: SOBGEQ R2,10$ ; Loop through all nexuses.
05 04EC 1147 RSB ; Return.
```

```

04ED 1149      .SBTTL  ENAB Action Routines
04ED 1150      ++
04ED 1151
04ED 1152      FUNCTIONAL DESCRIPTION:
04ED 1153      These action routines re-enable CRD interrupts for each 11/780 memory
04ED 1154      controller.  Memory types currently supported:
04ED 1155
04ED 1156      MS780C (local memory - 4k and 16k chips)
04ED 1157      MS780E (local memory - 64k chips)
04ED 1158      MA780  (multiport memory)
04ED 1159
04ED 1160      INPUTS:
04ED 1161      R2      - TR# of this memory
04ED 1162      R4      - address of EXESGL_CONFREGL array
04ED 1163      R5      - address of MMGSGL_SBICONF array
04ED 1164
04ED 1165      OUTPUTS:
04ED 1166      R0,R1 destroyed; all other registers preserved.
04ED 1167
04ED 1168      --
04ED 1169      ENAB_MS780C:
08 A1      51      6542      D0 04ED 1171      MOVL      (R5)[R2],R1      ; Get address of controller registers.
30000000 8F      D0 04F1 1172      MOVL      #<MRC$M_ELSRF!MRC$M_HERIMF>,8(R1) ; Enable interrupts
; and clear error flags.
05      04F9 1173      RSB      ; That's it.
04FA 1176
04FA 1177      ENAB_MS780E:
08 A1      51      6542      D0 04FA 1179      MOVL      (R5)[R2],R1      ; Get address of controller registers.
30000000 8F      D0 04FE 1180      MOVL      #<MRC$M_ELSRF!MRC$M_HERIMF>,8(R1) ; Enable interrupts
; and clear error flags in 1st contr.
0C A1      30000000 8F      D0 0506 1181      MOVL      #<MRC$M_ELSRF!MRC$M_HERIMF>,12(R1) ; Enable interrupts
; and clear error flags in 2nd contr.
05      050E 1183      RSB      ; That's it.
050F 1186
050F 1187      ENAB_MA780:
51      6542      D0 050F 1188      MOVL      (R5)[R2],R1      ; Get address of controller registers.
10 A1      30000000 8F      C8 0513 1190      $PRTCTINI B*10$, -      ; Protect against non-existent memory
; machine checks.
0513 1191      BISL      #<MCHK$M_LOG!MCHK$M_NEXM>,16(R1) ; Enable interrupts
; and clear error flags.
0527 1194      $PRTCTEND 10$      ; End of protected code.
05      0527 1196      RSB      ; That's it.
0528 1198

```



```

0529 1200 .SBTTL LOGMEM Action Routines
0529 1201 :++
0529 1202 FUNCTIONAL DESCRIPTION:
0529 1203 One action routine per memory controller type follows. These
0529 1204 routines create an 11/780 memory error log entry. Currently, the
0529 1205 following memory controllers are supported:
0529 1206
0529 1207 MS780C (local memory - 4K and 16K chips)
0529 1208 MS780E (local memory - 64K chips)
0529 1209 MA780 (multiport memory)
0529 1210
0529 1211 Each action routine contributes to the common error log buffer being
0529 1212 built on the stack. Because different routines are being used to build
0529 1213 a common error log buffer on the stack, the contents of the stack is
0529 1214 significant at all times.
0529 1215
0529 1216 INPUTS:
0529 1217 R2 - nexus index for this memory (TR #)
0529 1218 R3 - not available for use by action routines
0529 1219 R4 - address of SBI configuration array (CONFREGL)
0529 1220 R5 - current errorlog byte count
0529 1221 R6 - current number of controllers logged
0529 1222 R7 - address of array of SBI virtual addresses (SBICONF)
0529 1223 R8-R11 - scratch
0529 1224 AP - memory controller status: LBC = fatal controller error discovered
0529 1225
0529 1226 IMPLICIT INPUTS:
0529 1227
0529 1228 (SP): +-----+
0529 1229 | caller's return address |
0529 1230 +-----+
0529 1231 | return to caller's caller |
0529 1232 +-----+
0529 1233 | previous error log |
0529 1234 | : |
0529 1235 +-----+
0529 1236
0529 1237 OUTPUTS:
0529 1238 R2-R4 preserved
0529 1239 R5 and R6 updated
0529 1240
0529 1241 IMPLICIT OUTPUTS:
0529 1242
0529 1243 (SP): +-----+
0529 1244 | return to caller's caller |
0529 1245 +-----+
0529 1246 | error log entry for this controller |
0529 1247 | (null if no error for this memory) |
0529 1248 +-----+
0529 1249 | previous error log |
0529 1250 | : |
0529 1251 +-----+
0529 1251 :--

```

```
0529 1253 .SBTTL LOG_MS780C
0529 1254
0529 1255 ++ LOG_MS780C - Build error log for MS780C memory controller
0529 1256
0529 1257 The portion of the error log built for the MS780C memory controller
0529 1258 has the following format:
0529 1259
0529 1260 +-----+
0529 1261 | adapter TR# |
0529 1262 +-----+
0529 1263 | memory register A |
0529 1264 +-----+
0529 1265 | memory register B |
0529 1266 +-----+
0529 1267 | memory register C |
0529 1268 +-----+
0529 1269 Register A contains the type code in the low-order byte. For MS780C
0529 1270 memories, this type code is in the range of 8 - 11 (hex).
0529 1271
0529 1272 -- LOG_MS780C:
0529 1273
0529 1274 Determine whether to log this controller.
0529 1275
0529 1277 MOVL (R7)[R2],R8 ; Get VA of controller registers.
0529 1278 MOVL 8(R8),R10 ; Read memory controller register C.
0531 1279 BBS #MRC$V_ELSRF,R10,LOGC ; Branch if error log requested.
0535 1283 RSB ; Else return.
0536 1285
0536 1286 Build error log on stack.
0536 1287 This is the entry point used when unconditionally logging all memories.
0536 1288
0536 1289 LOGC:
0536 1290 POPR #M<R0,R1> ; Get return addr in R0, caller's
0538 1291 ; return in R1.
0538 1292 DSBINT DST=R9 ; Raise IPL while reading registers.
0538 1293 PUSHL R10 ; Save memory register C in log.
0540 1294 PUSHL 4(R8) ; Save memory register B in log.
0543 1295 PUSHL (R8) ; Save memory register A in log.
0545 1296 ENBINT SRC=R9 ; Drop back to previous IPL.
0548 1297 PUSHL R2 ; Save TR# in log.
054A 1298
054A 1299 Check for CRD error. If the number of recent CRD errors > CRDINTMAX, then
054A 1300 disable CRD interrupts. If the number of recent CRD errors > CRDWATCHMAX,
054A 1301 then stop logging CRD errors.
054A 1302
054A 1303 BBC #MRC$V_ELSRF,R10,20$ ; Branch if no error log requested.
054E 1304 INCB W^AB_MEMERR[R2] ; Count memory errors for this contr.
0553 1305 CMPB W^AB_MEMERR[R2],#CRDINTMAX ; Too many CRD interrupts?
0559 1306 BLEQ 10$ ; No, skip CRD interrupt disable.
055B 1307 BBSS #MRC$V_INHBCRD,R10,10$ ; Set bit to inhibit CRD interrupts.
055F 1308 10$:
055F 1309 CMPB W^AB_MEMERR[R2],#CRDWATCHMAX ; Too many CRD error logs?
0565 1310 BLEQ 20$ ; No, go log this one.
0567 1311 ADDL2 #<4*4>,SP ; Pop memory CSRs from stack.
056A 1312 BRB 30$ ; Skip logging CRD for this controller.
056C 1313 20$:
056C 1314 ADDL2 #<4*4>,R5 ; Add # of bytes in this log to total.
```

58 6742 DO 0529 1277  
5A 08 AB DO 0529 1278  
01 5A 1C EO 0531 1279  
05 0535 1283  
0536 1285  
0536 1286  
0536 1287  
0536 1288  
0536 1289  
03 BA 0536 1290  
0538 1291  
0538 1292  
5A DD 0538 1293  
04 AB DD 0540 1294  
68 DD 0543 1295  
52 DD 0545 1296  
0548 1297  
054A 1298  
054A 1299  
054A 1300  
054A 1301  
054A 1302  
1E 5A 1C E1 054A 1303  
0010'CF42 96 054E 1304  
03 0010'CF42 91 0553 1305  
04 15 0559 1306  
00 5A 1E E2 055B 1307  
055F 1308  
06 0010'CF42 91 055F 1309  
05 15 0565 1310  
5E 10 C0 0567 1311  
05 11 056A 1312  
056C 1313  
55 10 C0 056C 1314

MCHECK780  
V04-000

- MACHINE CHECK EXCEPTION HANDLER FOR 11 16-SEP-1984 00:43:58 VAX/VMS Macro V04-00 Page 29  
LOG\_MS780C 5-SEP-1984 04:10:29 [SYSLOA.SRC]MCHECK780.MAR;1 (23)

	56	D6	056F	1315		INCL	R6		; Count number of controllers logged.
			0571	1316	30\$:				
08 A8	5A	D0	0571	1317		MOVL	R10,8(R8)		; Clear errors from register C.
	51	DD	0575	1318		PUSHL	R1		; Restore caller's caller to stack.
	60	17	0577	1319		JMP	(R0)		; Return to caller.



```
0579 1322 .SBTTL LOG_MS780E
0579 1323 ++
0579 1324 LOG_MS780E - Build error log for MS780E memory controller
0579 1325
0579 1326 The portion of the error log built for the MS780E memory controller
0579 1327 has the following format:
0579 1328
0579 1329 +-----+
0579 1330 | adapter TR# |
0579 1331 +-----+
0579 1332 | memory register A |
0579 1333 +-----+
0579 1334 | memory register B |
0579 1335 +-----+
0579 1336 | memory register C |
0579 1337 +-----+
0579 1338 | memory register D |
0579 1339 +-----+
0579 1340
0579 1341 Register A contains the type code in the low-order byte. For MS780E
0579 1342 memories, this type code is in the range of 68 - 6C (hex).
0579 1343 --
0579 1344
0579 1345 LOG_MS780E:
0579 1346
0579 1347 Determine whether to log any errors for this controller.
0579 1348
0579 1350 MOVL (R7)[R2],R8 ; Get VA of controller registers.
0579 1351 BITL #MRC$M_SUMMARY,(R8) ; Test error summary bit in Register A.
0584 1352 BNEQ LOGE ; Branch if there are any errors.
0586 1353 RSB ; Else return.
0587 1354
0587 1355
0587 1356 This is the entry point used when unconditionally logging all memories.
0587 1357
0587 1358 LOGE:
0587 1359 POPR #^M<R0,R1> ; Get return address in R0, caller's
0589 1360 ; return in R1.
0589 1361 MOVN #3,R9 ; Initialize loop counter.
0589 1362 DSBINT DSI=R10 ; Raise IPL while reading registers.
0592 1363 10$: PUSHN (R8)[R9] ; Push registers in reverse order.
0595 1364 SOBGEQ R9,10$ ; Push 4 registers for error log.
0598 1365 PUSHN R2 ; Save TR# in error log.
059A 1366 ENBINT SRC=R10 ; Drop back to previous IPL.
059D 1367
059D 1368 The MS780E memory subsystem consists of 1 SBI Interface module and 2 Memory
059D 1369 Controller modules. Each controller can control up to 8 memory array cards.
059D 1370 The MS780E subsystem can operate in any one of 3 interleave modes: when both
059D 1371 Control Cards are present, the subsystem will usually operate in internally
059D 1372 interleaved mode; if only one Control Card is present, the sub-system may
059D 1373 operate in non-interleaved mode, or may be externally interleaved with
059D 1374 another memory subsystem on a different SBI slot.
059D 1375
059D 1376 MS780E controller registers A and B reside on the SBI Interface module and
059D 1377 are always accessible and valid when the subsystem is present. Register C
059D 1378 gives information about the lower controller and array cards while Register
059D 1379 D gives information about the upper set. If either controller is not
```

```
059D 1384 : present, its status register (C or D) will be accessible but the contents
059D 1385 : are UNDEFINED.
059D 1386 :
04 68 04 AE D0 059D 1387 :      MOVL 4(SP),(R8) : Clear error bits set in Register A.
04 A8 08 AE D0 05A1 1388 :      MOVL 8(SP),4(R8) : Clear error bits set in Register B.
05A6 1389 :
05A6 1390 : Check Register A for interleave mode.
05A6 1391 :
05 04 AE 59 7C 05A6 1392 :      CLRQ R9 : Will hold copies of Register C and D.
05A8 1393 :      BBS #2,4(SP),LOWER : If internally interleaved, check both
05AD 1394 : : upper and lower controllers.
11 04 AE 01 E0 05AD 1395 :      BBS #1,4(SP),UPPER : Branch if upper controller is enabled.
05B2 1396 :
05B2 1397 : Check lower controller for fatal parity errors.
05B2 1398 :
05B2 1399 : LOWER:
59 0C AE D0 05B2 1400 :      MOVL 12(SP),R9 : Get copy of Register C from stack.
3F 59 07 E0 05B6 1401 :      BBS #MRC$V_MSEQPTY,R9,- : Branch if microsequencer parity
05BA 1402 : FATAL_MEM : error.
3B 59 08 E0 05BA 1403 :      BBS #MRC$V_IFPTY,R9,- : Branch if SBI Interface write data
05BE 1404 : FATAL_MEM : parity error.
10 04 AE 02 E1 05BE 1405 :      BBC #2,4(SP),CHK_CRD_LOW : Branch if not internally interleaved.
05C3 1406 :
05C3 1407 : Check upper controller for fatal parity errors.
05C3 1408 :
05C3 1409 : UPPER:
5A 10 AE D0 05C3 1410 :      MOVL 16(SP),R10 : Get copy of Register D from stack.
2E 5A 07 E0 05C7 1411 :      BBS #MRC$V_MSEQPTY,R10,- : Branch if microsequencer parity
05CB 1412 : FATAL_MEM : error.
2A 5A 08 E0 05CB 1413 :      BBS #MRC$V_IFPTY,R10,- : Branch if SBI interface write data
05CF 1414 : FATAL_MEM : parity error.
05CF 1415 :
05CF 1416 : Determine if this error was a CRD in either controller.
05CF 1417 :
04 5A 09 E0 05CF 1418 :      BBS #MRC$V_CRDERR,R10,CRD_MS780E ; Branch if CRD error in upper contr.
05D3 1419 : CHK_CRD_LOW:
24 59 09 E1 05D3 1420 :      BBC #MRC$V_CRDERR,R9,LOG_E ; Branch if not a CRD error in lower.
05D7 1421 :
05D7 1422 : This was a CRD error. If the number of recent CRD errors > CRDINTMAX, then
05D7 1423 : disable CRD interrupts for this subsystem. If the number of recent CRD
05D7 1424 : errors > CRDWATCHMAX, then don't log another CRD error.
05D7 1425 :
05D7 1426 : NOTE: it is always safe to write to both register C and D even if one of the
05D7 1427 : controllers is disabled.
05D7 1428 :
05D7 1429 : CRD_MS780E:
03 0010'CF42 96 05D7 1430 :      INCB W^AB_MEMERR[R2] : Count memory errors for this contr.
0010'CF42 91 05DC 1431 :      CMPB W^AB_MEMERR[R2],#CRDINTMAX : Too many CRD interrupts?
00 08 15 05E2 1432 :      BLEQ 11$ : No, skip CRD interrupt disable.
00 59 1E E2 05E4 1433 :      BBSS #MRC$V_INHBCRD,R9,10$ : Set bit to inhibit CRD interrupts.
00 5A 1E E2 05E8 1434 :      BBSS #MRC$V_INHBCRD,R10,11$ : Set bit to inhibit in upper contr.
05EC 1435 :
06 0010'CF42 91 05EC 1436 :      CMPB W^AB_MEMERR[R2],#CRDWATCHMAX : Too many CRD error logs?
00 07 15 05F2 1437 :      BLEQ LOG_E : No, go ahead and log this one.
00 5E 14 C0 05F4 1438 :      ADDL2 #<5*4>,SP : Pop memory CSRs from stack.
00 07 11 05F7 1439 :      BRB CLEAR_ERRS_E : Skip logging CRDs for this controller.
05F9 1440 :
```

```

05F9 1441 : Found a fatal controller error. Report it, try to log the error and return.
05F9 1442 :
05F9 1443 FATAL_MEM:
5C D4 05F9 1444 CLRL AP ; Signal fatal memory error.
05FB 1445 :
05FB 1446 : Increment log counts.
05FB 1447 :
05FB 1448 LOG_E:
55 14 C0 05FB 1449 ADDL2 #<5*4>,R5 ; Add # of bytes in this log to total.
56 D6 05FE 1450 INCL R6 ; Count number of controllers logged.
0600 1451 CLEAR_ERRS_E:
08 A8 59 D0 0600 1452 MOVL R9,8(R8) ; Clear errors from register C.
0C A8 5A D0 0604 1453 MOVL R10,12(R8) ; Clear errors from register D.
51 DD 0608 1454 PUSHL R1 ; Restore caller's caller to stack.
60 17 060A 1455 JMP (R0) ; Return to caller.

```



```
060C 1458 .SBTTL LOG_MA780
060C 1459 :++
060C 1460 LOG_MA780 - Build error log for MA780 memory controller
060C 1461 :
060C 1462 The portion of the error log built for the MA780 memory controller
060C 1463 has the following format:
060C 1464 +-----+
060C 1465 | adapter TR# |
060C 1466 +-----+
060C 1467 | Port Configuration Register |
060C 1468 +-----+
060C 1469 | Port Interface Control Reg |
060C 1470 +-----+
060C 1471 | Port Controller Status Reg |
060C 1472 +-----+
060C 1473 | Port Invalidation Control Reg |
060C 1474 +-----+
060C 1475 | Array Error Register |
060C 1476 +-----+
060C 1477 | Configuration Status Reg 0 |
060C 1478 +-----+
060C 1479 | Configuration Status Reg 1 |
060C 1480 +-----+
060C 1481 | Maintenance Control Register |
060C 1482 +-----+
060C 1483 :
060C 1484 The Port Configuration Register contains the type code in the
060C 1485 low-order byte. For MA780 memories, this type code is in the
060C 1486 range of 40 - 43 (hex).
060C 1487 :
060C 1488 :--
060C 1489 :
060C 1490 LOG_MA780:
060C 1491 :
060C 1492 : Determine whether to log any errors for this controller.
060C 1493 :
060C 1494 :
060C 1495 :
0610 1496 :
0612 1497 :
0612 1499 :
0612 1500 :
061E 1502 :
0625 1503 :
0627 1504 :
062F 1505 :
0631 1506 :
0639 1507 :
063B 1508 :
0643 1509 :
0645 1510 :
064D 1511 :
064F 1512 :
0652 1513 :
0652 1515 :
0653 1516 :
0656 1518 :

58 6742 D0 060C 1495 MOVL (R7)[R2],R8 : Get VA of controller register.
5A D4 0610 1496 CLRL R10 : Use R10 as memory error flag; assume
: there is an error condition.
: Protect following code from
: all machine checks.
$PRCTINI B*10$, -
: #<MCHKSM LOG!MCHKSM_MCK>
BITL #X00400000,(R8) : Check for power-up interrupt.
BNEQ 5$ : Branch if found.
BITL #XFF000000,4(R8) : Check Port Interface Control Reg.
BNEQ 5$ : Branch if found error.
BITL #MRC$M_ELSRF,16(R8) : Check Array Error register.
BNEQ 5$ : Branch if found error.
BITL #X00000400,24(R8) : Check Multiple Interlock Accepted err.
BNEQ 5$ : Branch if found error.
BITL #XD000C000,8(R8) : Lastly, check Port Contr. Status Reg.
BNEQ 5$ : Branch if found error.
MOVL #1,R10 : Signal no errors found.

5$:
$PRCTEND 10$ : End of protected code.
BLBC R0,20$ : If MA780 has disappeared, just return.
BLBC R10,LOGMA : If any errors were found, log them.
```

```
05 0659 1519 20$: RSB ; Else return.
065A 1520
065A 1521 : This is the entry point used when unconditionally logging all memories.
065A 1522
065A 1523 : Build error log on stack. First set SP to where the top of the buffer
065A 1524 : will be, and use R9 as a temporary stack pointer while the log is being
065A 1525 : built. This is so the machine check protection routines can freely use the
065A 1526 : stack above where the error log is being built.
065A 1527
065A 1528 LOGMA:
0802 8F BA 065A 1529 POPR #^M<R1,R11> ; Get return address in R1, caller's
065E 1530 ; return in R11.
59 5E DO 065E 1531 MOVL SP,R9 ; Use R9 as temporary stack pointer.
5E 24 C2 0661 1532 SUBL #<9*4>,SP ; Point SP to where stack top will be.
0664 1533 $PRTCTINI W^50$ - ; Protect following code from
0664 1534 #<MCHKSM_LOG!MCHKSM_NEXM> ; non-existent memory errors.
0671 1537 DSBINT DST=R10 ; Raise IPL while logging registers.
79 1C A8 DO 0677 1538 MOVL 28(R8),-(R9) ; Maintenance Control Register
79 18 A8 DO 067B 1539 MOVL 24(R8),-(R9) ; Configuration Status Register 1
79 14 A8 DO 067F 1540 MOVL 20(R8),-(R9) ; Configuration Status Register 0
79 10 A8 DO 0683 1541 MOVL 16(R8),-(R9) ; Array Error Register
79 0C A8 DO 0687 1542 MOVL 12(R8),-(R9) ; Port Invalidation Control Register
068B 1544 $PRTCTINI B^10$,- ; Protect this register access against
068B 1545 #<MCHKSM_LOG!MCHKSM_MCK> ; all machine checks.
79 08 A8 DO 0697 1547 MOVL 8(R8),-(R9) ; Read Port Controller Status Register.
069B 1549 $PRTCTEND 10$ ; End of protected code.
03 50 E8 069C 1550 BLBS R0,15$ ; Branch if no machine check occurred.
79 00 DO 069F 1552 MOVL #0,-(R9) ; Else put fake copy of register in log.
06A2 1553 15$:
79 04 A8 DO 06A2 1554 MOVL 4(R8),-(R9) ; Port Interface Control Register
79 68 DO 06A6 1555 MOVL (R8),-(R9) ; Port Configuration Register
06A9 1556 ENBINT SRC=R10 ; Restore IPL to previous level.
79 52 DO 06AC 1557 MOVL R2,-(R9) ; Save TR# in error log.
06AF 1558 ;
06AF 1559 ; Clear errors from registers.
06AF 1560
04 68 04 A9 C8 06AF 1561 BISL 4(R9),(R8) ; Clear errs in Port Config Reg (pwr-up)
04 A8 08 A9 C8 06B3 1562 BISL 8(R9),4(R8) ; Clear errors in Port Interface
06B8 1563 ; Control Register.
06B8 1565 $PRTCTINI B^20$,- ; Protect this register access against
06B8 1566 #<MCHKSM_LOG!MCHKSM_MCK> ; all machine checks.
08 A8 0C A9 C8 06C4 1568 BISL 12(R9),8(R8) ; Clear errors in Port Controller
06C9 1569 ; Status register.
06C9 1571 $PRTCTEND 20$ ; End of protected code.
14 A8 18 A9 C8 06CA 1573 BISL 24(R9),20(R8) ; Clear errors in Port Configuration
06CF 1574 ; Status Register (Mult Interlock Acpt)
14 A9 DD 06CF 1575 PUSHL 20(R9) ; Get copy of Array Error Register
06D2 1576 ; on top of stack.
06D2 1577 ;
06D2 1578 ; Check for CRD error. If the # of recent CRD errors > CRDINTMAX, then disable
06D2 1579 ; CRD interrupts for this controller. If the # of recent CRD errors >
06D2 1580 ; CRDWATCHMAX, then don't log another CRD error for this controller.
06D2 1581 ;
06D2 1582
1E 6E 1C E1 06D2 1582 BBC #MRC$V_ELSRF,(SP),40$ ; Branch if this wasn't a data error.
0010'CF42 96 06D6 1583 INCB W^AB_MEMERR[R2] ; Count data errors for this contr.
03 0010'CF42 91 06DB 1584 CMPB W^AB_MEMERR[R2],#CRDINTMAX ; Too many CRD interrupts?
04 15 06E1 1585 BLEQ 30$ ; No, skip CRD interrupt disable.
```

```
00 6E 1E E2 06E3 1586 BBSS #MRC$V_INHBCRD,(SP),30$ ; Set bit to inhibit CRD interrupts.
06 5A 01 D0 06E7 1587 30$: MOVL #1,R10 ; Assume error will be logged.
0010'CF42 91 06EA 1588 CMPB W^AB_MEMERR[R2],#CRDWATCHMAX ; Too many CRD error logs?
02 15 06F0 1589 BLEQ 40$ ; No, go ahead and log this one.
5A D4 06F2 1591 CLRL R10 ; Signal "don't log this error".
10 A8 8E D0 06F4 1592 40$: MOVL (SP)+,16(R8) ; Clear errors from Array Error Reg.
06F8 1594 SPRTCTEND 50$ ; End of protected code.
06F8 1596
06F9 1598 ; Note: If no machine check occurred, R9 and SP are now identical. We can
06F9 1599 ; resume using SP.
06F9 1600
06F9 1601
03 50 E9 06F9 1603 BLBC R0,NOLOG_MA ; MA780 disappeared, nothing to log
05 5A E8 06FC 1605 BLBS R10,LOG_MA ; Branch to log the error.
06FF 1607 NOLOG_MA:
5E 24 C0 06FF 1608 ADDL #<9*4>,SP ; Clean error log off the stack.
05 11 0702 1609 BRB EXIT_MA ; And return.
0704 1611 LOG_MA:
55 24 C0 0704 1612 ADDL #<9*4>,R5 ; Add # of bytes in this log to total.
56 D6 0707 1613 INCL R6 ; Increment count of memories logged.
0709 1614 EXIT_MA:
5B DD 0709 1615 PUSHL R11 ; Restore caller's caller to stack.
61 17 070B 1616 JMP (R1) ; Return to caller.
```



```

      070D 1618      .SBTTL TABLE OF RESUMABLE INSTRUCTIONS.
      070D 1619      : EACH BIT IN THE TABLE IS A 1 IF THE INSTRUCTION IS RESUMABLE,
      070D 1620      : AND A 0 IF IT IS NOT.
      070D 1621
      070D 1622 RESUMABLE:
3C3B  070D 1623      .WORD  ^B00111110000111011      :REI, LDPCTX, SVPCTX, INSQUE, REMQUE
      070F 1624      :CVTSP, CVTSP
FFFF  070F 1625      .WORD  ^B11111111111111111
FF00  0711 1626      .WORD  ^B11111111000000000      :PACKED DECIMAL INSTRUCTIONS
FEFF  0713 1627      .WORD  ^B11111110111111111      :EDITPC
FFFF  0715 1628      .WORD  ^B11111111111111111
002F  0717 1629      .WORD  ^B00000000000101111      :EMODF, CVTFD, INTERLOCKED INSTRUCTIONS
0F00  0719 1630      .WORD  ^B00001111000000000      :DOUBLE PRECISION FLOATING POINT
C14A  071B 1631      .WORD  ^B1100000101001010      :MORE DOUBLE PREC/QUAD, EMUL, EDIV
FFFF  071D 1632      .WORD  ^B11111111111111111
FFFF  071F 1633      .WORD  ^B11111111111111111
FFFF  0721 1634      .WORD  ^B11111111111111111
F3FF  0723 1635      .WORD  ^B11110011111111111      :PUSHR, POPR
FFFF  0725 1636      .WORD  ^B11111111111111111
F4FF  0727 1637      .WORD  ^B11110100111111111      :ADWC, SBWC, MFPR
FF3F  0729 1638      .WORD  ^B11111111001111111      :BBSSI, BBCCI
00FF  072B 1639      .WORD  ^B00000000111111111      :ASHP, CVTLP, CALLG, CALLS, XFC, EXPANSION
      072D 1640
      072D 1641      .end

```

MCHECK780  
Symbol table

F 12  
- MACHINE CHECK EXCEPTION HANDLER FOR 11 16-SEP-1984 00:43:58 VAX/VMS Macro V04-00  
5-SEP-1984 04:10:29 [SYSLOA.SRC]MCHECK780.MAR;1

Page 37  
(26)

AB MEMERR	00000010	R	07
ADPSL_LINK	= 00000004		
ADPSL_UBASCB	= 00000044		
ADPSW_ADPTYPE	= 0000000E		
AMPUTATE	000000B7	R	08
ATS_UBA	*****	X	08
BADTYPE	0000004D	R	08
BAMPUTATE	0000022E	R	08
BRESUM	00000157	R	08
BUGS_ASYNCWRTER	*****	X	08
BUGS_BADMCKCOD	*****	X	08
BUGS_MACHINECHK	*****	X	08
BUGS_RDSNONRES	*****	X	08
CACHEPARITY	000000F9	R	08
CHSS_CONTROL	= 00000004		
CHSS_GOERRS	= 00000007		
CHSV_GOERRS	= 00000003		
CHSV_REPLG1	= 0000000D		
CHK_CRD_LOW	000005D3	R	08
CHLOG_DISAB0	= 00000001		
CHLOG_DISAB1	= 00000002		
CH_MISSGO	= 00010000		
CH_MISSG1	= 00008000		
CH_REPAIR	= 0021C000		
CH_REPAIR_1	= 0021A000		
CH_REPLGO	= 00004000		
CH_REPLG1	= 00002000		
CH_THRESHOLD	= 0000000A		
CLEAR_ERRS_E	00000600	R	08
CPTIMEOUT	0000015A	R	08
CRDINTMAX	= 00000003		
CRDWATCHMAX	= 00000006		
CRD_MS780E	000005D7	R	08
CSPARITY	000000A9	R	08
DAMPUTATE	00000086	R	08
ECC\$REENABLE	000003E6	RG	08
EMBSB_MC_SUMCOD	= 00000010		
EMBSK_AW	= 00000007		
EMBSK_BE	= 00000004		
EMBSK_HE	= 00000008		
EMBSK_MC	= 00000002		
EMBSK_SA	= 00000005		
EMBSK_SE	= 00000006		
EMBSW_MC_ENTRY	= 00000004		
ENAB_MA780	0000050F	R	08
ENAB_MS780C	000004ED	R	08
ENAB_MS780E	000004FA	R	08
ENAB_ROUTINES	00000000	R	05
ERL\$ALLOCEMB	*****	X	08
ERL\$RELEASEMB	*****	X	08
EXESAB_MEMERR	00000010	RG	07
EXESGL_BADTIMOUT	0000002C	RG	07
EXESGL_CH1OLD	00000004	RG	07
EXESGL_CH2OLD	00000008	RG	07
EXESGL_CHSTATE	00000028	RG	07
EXESGL_CONFREGL	*****	X	08
EXESGL_CPTIMOUT	0000000C	RG	07

EXESGL_CRDCNT	00000024	RG	07
EXESGL_CSBITA	00000000	RG	07
EXESGL_FLAGS	*****	X	08
EXESGL_MCHKERRS	*****	X	08
EXESGL_MEMERRS	*****	X	08
EXESGL_NUMNEXUS	*****	X	08
EXESGW_REENAB	00000020	RG	07
EXESGW_WATCH	00000022	RG	07
EXESINT54	00000044C	RG	08
EXESINT58	000000438	RG	08
EXESINT5C	000000328	RG	08
EXESINT60	00000033C	RG	08
EXESLOGAWE	00000033C	RG	08
EXESLOGCRD	00000044C	RG	08
EXESLOGSBA	000000438	RG	08
EXESLOGSBF	000000328	RG	08
EXESMCKCHK	*****	X	08
EXESMCHK	00000000	RG	08
EXESMCHK_BUGCHK	*****	X	08
EXESMCHK_ERRCNT	00000000	RG	07
EXESMCHK_PRTCT	*****	X	08
EXESMCHK_TEST	*****	X	08
EXESV_CRDENABL	*****	X	08
EXIT_MA	00000709	R	08
FATAL_MEM	000005F9	R	08
GENERAL_MEMTYP	= 00000003		
GL_BADTIMOUT	0000002C	R	07
GL_CH1OLD	00000004	R	07
GL_CH2OLD	00000008	R	07
GL_CHSTATE	00000028	R	07
GL_CPTIMOUT	0000000C	R	07
GL_CRDCNT	00000024	R	07
GL_CSBITA	00000000	R	07
GW_REENAB	00000020	R	07
GW_WATCH	00000022	R	07
IBROMCHECK	000000A9	R	08
INT54	00000044C	R	08
INT58	000000438	R	08
INT5C	000000328	R	08
INT60	00000033C	R	08
IOC\$GL_ADPLIST	*****	X	08
IPL\$ASTDEL	= 00000002		
LOCATE_MEM	0000004C0	R	08
LOGALL_ROUTINES	00000000	R	04
LOGAWE	00000033C	R	08
LOGC	000000536	R	08
LOGCRD	00000044C	R	08
LOGE	000000587	R	08
LOGERR_ROUTINES	00000000	R	03
LOGGER	0000002CC	R	08
LOGIT	0000002E7	R	08
LOGMA	00000065A	R	08
LOGMEM	000000476	R	08
LOGSBA	000000438	R	08
LOGSBF	000000328	R	08
LOGSBI	00000037A	R	08
LOG_ALL_MEM	00000046D	R	08

MCHI  
V04

MCHECK780  
Symbol table

G 12

- MACHINE CHECK EXCEPTION HANDLER FOR 11 16-SEP-1984 00:43:58 VAX/VMS Macro V04-00 Page 38  
5-SEP-1984 04:10:29 [SYSLOA.SRC]MCHECK780.MAR;1 (26)

LOG_E	000005FB	R	08	NDTS-MEM16I	= 00000011		
LOG_ERROR_MEM	00000462	R	08	NDTS-MEM16NI	= 00000010		
LOG_MA	00000704	R	08	NDTS-MEM256EIL	= 00000071		
LOG_MA780	0000060C	R	08	NDTS-MEM256EIU	= 00000073		
LOG_MS780C	00000529	R	08	NDTS-MEM256I	= 00000074		
LOG_MS780E	00000579	R	08	NDTS-MEM256NIL	= 00000070		
LOWER	000005B2	R	08	NDTS-MEM256NIU	= 00000072		
MCHK	00000000	R	08	NDTS-MEM4I	= 00000009		
MCHK\$GL_LOG	00000305	RG	08	NDTS-MEM4NI	= 00000008		
MCHK\$M_COG	= 00000001			NDTS-MEM64EIL	= 00000069		
MCHK\$M_MCK	= 00000002			NDTS-MEM64EIU	= 0000006B		
MCHK\$M_NEXM	= 00000004			NDTS-MEM64I	= 0000006C		
MCHK_ERRCNT	00000000	R	07	NDTS-MEM64NIL	= 00000068		
MCL_CES	= 00000008			NDTS-MEM64NIU	= 0000006A		
MCL_COUNT	= 00000000			NDTS-MPM0	= 00000040		
MCL_D	= 00000014			NDTS-MPM1	= 00000041		
MCL_PARITY	= 00000024			NDTS-MPM2	= 00000042		
MCL_PC	= 0000002C			NDTS-MPM3	= 00000043		
MCL_PSL	= 00000030			NOLOG_MA	000006FF	R	08
MCL_SBIERR	= 00000028			PCBSL-PHD	= 0000006C		
MCL_SUMMARY	= 00000004			PFNSAB_STATE	*****	X	08
MCL_TBER0	= 00000018			PFNSAB_TYPE	*****	X	08
MCL_TBER1	= 0000001C			PFNSAW_REFCNT	*****	X	08
MCL_TMOADDR	= 00000020			PFNSAX_WSLX	*****	X	08
MCL_UPC	= 0000000C			PFNSC_BADPAGLST	= 00000002		
MCL_VA	= 00000010			PFNSC_PROCESS	= 00000000		
MEMTYP	00000000	R	02	PFNSC_SYSTEM	= 00000001		
MEMTYPCNT	= 00000012			PFNSM_BADPAG	= 00000020		
MMGSAL_SYSPCB	*****	X	08	PFNSM_MODIFY	= 00000080		
MMGSDE[CONPFN	*****	X	08	PFNSS_PAGTYP	= 00000003		
MMGSDELWSLEX	*****	X	08	PFNSV_PAGTYP	= 00000000		
MMGSGL_MAXPFN	*****	X	08	PR\$ IPL	= 00000012		
MMGSGL-SBICONF	*****	X	08	PR\$ KSP	= 00000000		
MMGSGL-BIGPFN	*****	X	08	PR\$ TBIA	= 00000039		
MMGSINSPFNT	*****	X	08	PR\$ TBIS	= 0000003A		
MMGSREFCNTNEG	*****	X	08	PR780\$-SBIER	= 00000034		
MMGS\$VAPTECHK	*****	X	08	PR780\$-SBIFS	= 00000030		
MRC\$M_CRDERR	= 00000200			PR780\$-SBIMT	= 00000033		
MRC\$M_CTLOPTY	= 00040000			PR780\$-SBIS	= 00000031		
MRC\$M_CTL1PTY	= 00080000			PR780\$-SBISC	= 00000032		
MRC\$M_ELSRF	= 10000000			PR780\$-SBITA	= 00000035		
MRC\$M-HERIMF	= 20000000			PR780\$-TODR	= 0000001B		
MRC\$M-IFPTY	= 00000100			PSL\$S_CURMOD	= 00000002		
MRC\$M-INHBCRD	= 40000000			PSL\$S-IPL	= 00000005		
MRC\$M-INVMAPPTY	= 80000000			PSL\$V_CURMOD	= 00000018		
MRC\$M-MSEQPTY	= 00000080			PSL\$V-IPL	= 00000010		
MRC\$M-SUMMARY	= 00100000			PSL\$V-PRVMOD	= 00000016		
MRC\$V_CRDERR	= 00000009			PTE\$S-PFN	= 00000015		
MRC\$V_CTLOPTY	= 00000012			PTE\$V-MODIFY	= 0000001A		
MRC\$V_CTL1PTY	= 00000013			PTE\$V-PFN	= 00000000		
MRC\$V-ELSRF	= 0000001C			PTE\$V-VALID	= 0000001F		
MRC\$V-HERIMF	= 0000001D			PTE\$V-WINDOW	= 00000015		
MRC\$V-IFPTY	= 00000008			RDSNORRES	000002BE	R	08
MRC\$V-INHBCRD	= 0000001E			READSUBST	000001BF	R	08
MRC\$V-INVMAPPTY	= 0000001F			REENABLE_INTS	00000405	R	08
MRC\$V-MSEQPTY	= 00000007			REENABTIME	= 00000384		
MRC\$V-SUMMARY	= 00000014			REFLECTCHK	000000D0	R	08

MCH  
V04

5F  
4F  
66  
6F

43  
6C  
74  
75



MCHECK780  
Symbol table

H 12

16-SEP-1984 00:43:58 VAX/VMS Macro V04-00 Page 39  
5-SEP-1984 04:10:29 [SYSLOA.SRC]MCHECK780.MAR;1 (26)

RESUMABLE	0000070D	R	08
RESUME	00000098	R	08
SBIERSM_CPTO	= 00001000		
SBIERSM_CRD	= 00004000		
SBIERSM_IBRDS	= 00000080		
SBIERSM_IBTO	= 00000040		
SBIERSM_RDS	= 00002000		
SBISSV_NEF	= 00000019		
SCH\$GL_CURPCB	*****	X	08
SOMETIME	= 0000003C		
SS\$ NORMAL	= 00000001		
TBUF PARITY	00000074	R	08
TRYRESUME	00000080	R	08
UPPER	000005C3	R	08

-----  
! Psect synopsis !  
-----

PSECT name	Allocation	PSECT No.	Attributes
. ABS .	00000000 ( 0.)	00 ( 0.)	NOPIC USR CON ABS LCL NOSHR NOEXE NORD NOWRT NOVEC BYTE
\$ABSS	00000000 ( 0.)	01 ( 1.)	NOPIC USR CON ABS LCL NOSHR EXE RD WRT NOVEC BYTE
MCHK\$DATA0	00000012 ( 18.)	02 ( 2.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC LONG
MCHK\$DATA2	0000000C ( 12.)	03 ( 3.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC LONG
MCHK\$DATA3	0000000C ( 12.)	04 ( 4.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC LONG
MCHK\$DATA4	0000000C ( 12.)	05 ( 5.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC LONG
MCHK\$DATA1	00000012 ( 18.)	06 ( 6.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE
MCHK\$DATA	00000030 ( 48.)	07 ( 7.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC QUAD
MCHK\$CODE	0000072D ( 1837.)	08 ( 8.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC LONG

-----  
! Performance indicators !  
-----

Phase	Page faults	CPU Time	Elapsed Time
Initialization	31	00:00:00.05	00:00:02.68
Command processing	107	00:00:00.39	00:00:04.01
Pass 1	416	00:00:09.91	00:00:35.99
Symbol table sort	6	00:00:01.26	00:00:05.80
Pass 2	282	00:00:02.90	00:00:11.71
Symbol table output	30	00:00:00.13	00:00:00.14
Psect synopsis output	2	00:00:00.03	00:00:00.03
Cross-reference output	0	00:00:00.00	00:00:00.00
Assembler run totals	876	00:00:14.68	00:01:00.36

The working set limit was 1800 pages.  
95397 bytes (187 pages) of virtual memory were used to buffer the intermediate code.  
There were 70 pages of symbol table space allocated to hold 1210 non-local and 53 local symbols.  
1641 source lines were read in Pass 1, producing 33 object records in Pass 2.  
42 pages of virtual memory were used to define 36 macros.



-----  
! Macro library statistics !  
-----

Macro library name

Macros defined

-----  
\$255\$DUA28:[SYS.OBJ]LIB.MLB;1  
\$255\$DUA28:[SYSLIB]STARLET.MLB;2  
TOTALS (all libraries)

-----  
23  
8  
31

1265 GETS were required to define 31 macros.

There were no errors, warnings or information messages.

MACRO/LIS=LIS\$:MCHECK780/OBJ=OBJ\$:MCHECK780 MSRC\$:MCHECK780/UPDATE=(ENH\$:MCHECK780)+EXECML\$/LIB



0397

AH-BT13A-SE  
VAX/VMS V4.0

DIGITAL EQUIPMENT CORPORATION  
CONFIDENTIAL AND PROPRIETARY